



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	47216	STARTER MOTOR ASSEMBLY, C	1	BOSCH SMF 12A 2	
1		48208	CAP ASSEMBLY, COMMUTATO	1		
2	10	48205	BOLT, THRU - CAP TO END PL	2		
3	13	26996	LOCKWASHER, THRU BOLT	2		
4		48211	SPRING AND BRUSH SET (2 PE	1		
5		48212	PLATE AND HOLDER ASSEMBL	1		
6		48213	TERMINAL ASSEMBLY, START	1		
7		48207	ARMATURE	1		
8	12	48468	WASHER, SPACING - ARMATUI	AR		3
9	10	48206	SCREW, STARTER MOTOR MC	2		
10		48209	END PLATE ASSEMBLY, DRIVE	1		
11		48210	DRIVE ASSEMBLY, COMPLETE	1		