



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	37345A 1	STARTER MOTOR ASSEMBLY, C	1	MO551014A	
-	50	38890A 1	STARTER MOTOR ASSEMBLY, C	.1	MO551017A	
1		31175	LOCKWASHER, PINION STOP C	1,1		
2		31176	COLLAR, PINION STOP	1,1		
3		32418	MOTOR DRIVE	1,1		
4	24	32407	SPRING, TENSION - MOTOR DR	1,1		
5		38007	PLATE ASSEMBLY, DRIVE END	1,1		
6	12	38008	WASHER, SHIMMING - ARMATI	1,1		
7	15	38009005	SHIM, END PLATE TO ARMATL	AR,AR		3
7	15	38009010	SHIM, END PLATE TO ARMATL	AR,AR		3
7	15	38009020	SHIM, END PLATE TO ARMATL	AR,AR		3
8		38010	ARMATURE	1		
8		39102	ARMATURE	.1		
9	12	38011	WASHER, THRUST - ARMATUR	1		
10	12	38012	WASHER, INSULATION - INPUT	1,1		
11	12	38013	WASHER, INPUT STUD	1,1		
12	13	26992	LOCKWASHER, INPUT STUD	1,1		
13	11	20890	NUT, INPUT STUD	1,1		
14			BRUSH, COMMUTATOR STAR	1,1	EACH KIT CONTAINS 2 BRUSHE	
15		38015	DISC, THRUST - ARMATURE	1,1		
16		38018	END CAP ASSEMBLY, COMMU	1		
16		39104	END CAP ASSEMBLY, COMMU	.1		
17	24	25655	SPRING, BRUSH	2	EACH KIT CONTAINS 2 BRUSHE	
17	24	39103	SPRING, BRUSH	.2	EACH KIT CONTAINS 2 BRUSHE	
18			BRUSH, END CAP	1,1	EACH KIT CONTAINS 2 BRUSHE	
19	10	38016	SCREW, BRUSH TO END CAF	1,1		
20	13	38019	LOCKWASHER, THRU BOLT	2,2		
21	10	38020	BOLT, THRU - END CAP TO DR	2		
21	10	39105	BOLT, THRU - END CAP TO DR	.2		