



| Parts List | | | | | |
|------------|-------|----------|-----------------------------|-----|----------|
| Ref | Class | Part | Description | Qty | Footnote |
| - | | 35651A 1 | REMOTE CONTROL ASSEMBLY, | 1 | 10 |
| 1 | | 35940 | HOUSING, REMOTE CONTROL | 1 | |
| 2 | 23 | 33589 | BUSHING, NYLON - SHIFT LEV | 1 | |
| 3 | | 35649 | LEVER, SHIFT | 1 | |
| 4 | 10 | 34676 | SCREW, SHIFT LEVER TO CON | 1 | |
| 5 | 12 | 34675 | WASHER, RETAINING - SHIF | 1 | |
| 6 | 17 | 35951 | PIN, CAM ROLLER TO SHIFT LE | 2 | |
| 7 | | 35943 | CAM ROLLER, SHIFT LEVER | 2 | |
| 8 | 12 | 35950 | WASHER, CAM ROLLER PIN | 2 | |
| 9 | 11 | 34688 | NUT, CAM ROLLER PIN | 2 | |
| 10 | 17 | 35944 | PIN, CONTROL CABLE TO SH | 1 | |
| 11 | 18 | 29623 | COTTER PIN, CONTROL TO SH | 1 | |
| 12 | | 35942 | ROLLER GUIDE, SHIFT LEVER | 2 | |
| 13 | 17 | 29908 | PIN, ROLLER GUIDE TO SHIF | 2 | |
| 14 | 18 | 36002 | COTTER PIN, CONTROL CABLE | 1 | |
| 15 | 23 | 34677 | BUSHING, NYLON - SHIFT CAM | 1 | |
| 16 | | 35650 | CAM, SHIFT | 1 | |
| 17 | 17 | 36241A 1 | PIN ASSEMBLY, BLOCKING - SF | 1 | |
| 18 | 24 | 36244 | SPRING, COMPRESSION - BL | 1 | |
| 19 | | 35819A 1 | SHAFT, CONTROL ASSEMBLY | 1 | |
| 20 | | 35648 | CAM, THROTTLE | 1 | |
| 21 | 23 | 34677 | BUSHING, NYLON - THROTTLE | 1 | |
| 22 | | 35649 | LEVER, THROTTLE | 1 | |
| 23 | 23 | 33589 | BUSHING, NYLON - THROTTLE | 1 | |
| 24 | 12 | 34675 | WASHER, RETAINING - THROT | 1 | |
| 25 | 10 | 34676 | SCREW, THROTTLE LEVER TC | 1 | |
| 26 | 17 | 35951 | PIN, CAM ROLLER TO THROTT | 1 | |
| 27 | | 35943 | CAM ROLLER, THROTTLE LEVI | 1 | |
| 28 | 12 | 35950 | WASHER, CAM ROLLER PIN | 1 | |
| 29 | 11 | 34688 | NUT, CAM ROLLER PIN | 1 | |
| 30 | | 35942 | ROLLER GUIDE, THROTTLE LE | 2 | |
| 31 | 17 | 29908 | PIN, ROLLER GUIDE TO THRO | 2 | |
| 32 | 17 | 35944 | PIN, CONTROL CABLE TO THR | 1 | |
| 33 | 18 | 29623 | COTTER PIN, CONTROL CABLE | 1 | |
| 34 | | 35941 | HOUSING, REMOTE CONTROL | 1 | |
| 35 | | 36047 | HANDLE, CONTROL | 1 | |
| 36 | | 34771 | GRIP, CONTROL HANDLE | 1 | |
| 37 | 10 | 37342 | SCREW, GRIP TO CONTROL H | 2 | |
| 38 | | 35956 | BUTTON, CONTROL HANDLE | 1 | |
| 39 | 10 | 35955 | SCREW, SET CONTROL HANDI | 1 | |