



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		29646A	1 REMOTE CONTROL ASSEMBLY (	1		
-		30063A	1 REMOTE CONTROL ASSEMBLY	.1		
1		29580	HOUSING, REMOTE CONTROL	1	(USE WITH A-43-29571 SECTOR	
1		30203	HOUSING, REMOTE CONTROL	.1	(USE WITH C-43-30904 SECTOR	
2		29640	PLATE, RACK RETAINING	2,2		
3	10	26668	SCREW, RACK RETAINING PL	4,4		
4	23	28314	BUSHING, NYLON - THROTTLE	2,2		
5		29574	ACTUATOR, LINK AND THROT	1,1		
6	23	29638	BUSHING, NYLON - THROTTLE	1,1		
7		29576	LINK, THROTTLE - ACTUATOR	1,1		
8	12	29629	WASHER, THROTTLE LINK	1,1		
9	18	29623	COTTER PIN, THROTTLE LINK	1,1		
10	43	29575	GEAR, DRIVE - ACTUATOR (DR	1,1	ORDER A-43-31371	
11		29647	PLATE, SEPARATOR - CONTRC	1,1		
12	10	29642	SCREW, SEPARATOR PLATE T	2,2		
13		29578A	1 THROTTLE SHAFT AND LINK A	1,1		
14	12	20583	WASHER, THROTTLE SHAFT	1,1		
15	18	21071	COTTER PIN, LINK TO THROT	1,1		
16		29573	BLOCK, CONTROL CABLE ANCI	1,1		
17	12	29626	WASHER, THROTTLE SHAFT L	1,1		
18	18	21071	COTTER PIN, LINK TO CABLE A	1,1		
19	12	29683	WASHER, THROTTLE SHAFT A	1,1		
20	43	29571	GEAR, THROTTLE SECTOR FU	1,1	USE WITH A-29580 STARBOARD	
20	43	30204	GEAR, THROTTLE SECTOR FU	.1	USE WITH C-30203 STARBOARD	
21	12	29629	WASHER, THROTTLE LINK	1,1		
22	53	29641	"E" RING, THROTTLE LINK TO	1,1		
23		29630	CAM FOLLOWER, THROTTLE L	1,1		
24	23	27132	BUSHING, NYLON - THROTTLE	2,2		
25	43	31802	GEAR, SHIFT SECTOR	1,1		
26	12	29627	WASHER, SHIFT SECTOR GEA	1,1		
27		30986	HOUSING, REMOTE CONTROL	1,1		
28	30	29634	BALL, TENSION - DRIVE GEAR	1,1	EARLY STYLE	
29	24	29622	SPRING, DETENT - DRIVE GEA	1,1	EARLY STYLE	
30		29838	HOUSING, DETENT SPRING	1,1	EARLY STYLE	
28		31370	BALL, TENSION - DRIVE GEAR	.1	LATEST STYLE	
29	24	30891	SPRING, DETENT - DRIVE GEA	.1	LATEST STYLE	
31	10	29837	SCREW, RETAINING - DETENT	1,1		
32	19	29540	PLUG, CHOKE SWITCH HOLE	1,		
32	19	30064	PLUG, CHOKE SWITCH HOLE	.1		
33	25	20034	"O" RING, CHOKE HOLE PLUG	1,		