



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
		45194A23	POWER TRIM KIT	1		
42	89	68258A 4	STARTER SOLENOID	1		
43	13	26996	LOCKWASHER (#10)	2		
44	11	68219	NUT (#10)	2		
45	13	26993	LOCKWASHER (5/16")	2		
46	11	68292	NUT (5/16")	2		
47		46265	BOOT	2		
48		74407T	BRACKET	1		
49	10	21140	SCREW	2		
50	13	26992	LOCKWASHER	2		
51	10	98256	SCREW	2		
52	13	26992	LOCKWASHER	2		
53	11	21825	NUT	2		
54	11	24656	NUT	1		
55		26901	BUMPER	1		
56		55642A13	CONTROL PANEL ASSEMBLY	1		
57		53107	JUMPER WIRE (PURPLE)	1		
57		48078	JUMPER WIRE (RED)	1		
58		55642A17	CONTROL PANEL	1		
59	16	55422	STUD	4		
60	12	24676	WASHER	4		
61	11	27164	NUT	4		
62		55738A 1	SWITCH	3		
63		55641	RETAINER	1		
64	10	62568	SCREW	4		
65	84	87394A20	HARNES (20')	1		
67	54	46770	CLAMP	1		
68	10	29227	SCREW	1		
69	11	34388	NUT	1		
70		92194A14	CYLINDER ASSEMBLY	2		
71	22	74036	GREASE FITTING	2		
72	10	45265	SCREW	4		
73	25	45016	O-RING	4		
74	10	71796	SCREW	2		
75	23	45280	SPACER	2		
76	23	94907A 1	BUSHING	2		
77		89108A 3	BRACKET (PORT)	1		
78	10	71797	SCREW	2		
79	10	68298	BOLT	4		
80	12	68410	WASHER	4		