



18610

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		38638A 4	POWER SHIFT ASSEMBLY	1		
2	16	36389	STUD, (.250-28 x .6875)	1		
3	11	30506	NUT, (.250-28)	1		
4	17	813578	PIN, Clevis	1		
5	18	21071	COTTER PIN	1		
6	12	87188	WASHER, (.27 x .44 x .062)	1		
7	10	16862	SCREW, (.250-10 x 1.25)	3		
8	12	35044	WASHER, (.281 x .625 x .065) St	3		
9	18	36002	COTTER PIN	1		
10		36149	WASHER, Felt	1		
11		36092	FLANGE	1		
12	27	36151	GASKET	1		
13	10	74824	SCREW, (.312-18 x 1.250)	2		
14	13	26993	LOCKWASHER, (.312)	2		
15		35809	DUST SHEILD	1		
16	54	815504256	CLAMP, Worm Gear	2		
17		36150	SPACER, Felt	1		
18	54	815504206	CLAMP, Worm Gear	2		
19	32	36164	HOSE, Vacuum	1		
20	54	815504206	CLAMP, Worm Gear	1		
21	22	32820	CONNECTOR	1		
22	23	36159	BUSHING	1		
23	22	65060	TEE FITTING	1		
24	37	37361 1	DECAL	1		
-	25	36125A 2	SEAL REPAIR KIT	1		