



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		52965A	FRESH WATER COOLING KIT (M...	1	
1		52966A	FRESH WATER COOLING KIT (M...	.1	
2		54767	BRACKET, MOUNTING - HEAT I	1	
2		54773	BRACKET, MOUNTING - HEAT I	1	
3	10	26486	SCREW, MOUNTING BRACKET	1	
3	10	45754	SCREW, MOUNTING BRACKET	1	
3	10	45363	SCREW, MOUNTING BRACKET	.2	
4	13	37458	LOCKWASHER, MOUNTING BR	2.2	
5	12	34664	WASHER, MOUNTING BRACKE	2.2	
6	23	54769	SPACER, MOUNTING BRACKET	1	
7	10	34354	SCREW, HEAT EXCHANGER TI	4.4	
8	13	37458	LOCKWASHER, HEAT EXCHAN	4.4	
9	11	32219	NUT, HEAT EXCHANGER SCRE	4.4	
10		54766	BRACKET, MOUNTING - HEAT I	1	
10		54774	BRACKET, MOUNTING - HEAT I	1	
11	10	48115	SCREW, MOUNTING BRACKET	1	
11	10	45363	SCREW, MOUNTING BRACKET	1	
11	10	45363	SCREW, MOUNTING BRACKET	.2	
12	13	37458	LOCKWASHER, MOUNTING BR	2.2	
13	12	34664	WASHER, MOUNTING BRACKE	2.2	
14		54765	BRACKET, TIE-DOWN - HEAT E	1	
14		54772	BRACKET, TIE-DOWN-HEATEX	.1	
15	10	33389	SCREW, BRACKET AND SPACE	.2	
16	10	37612	SCREW, TIE-DOWN BRACKET	1	
16	10	37612	SCREW, TIE-DOWN BRACKET	.2	
17	13	37458	LOCKWASHER, TIE-DOWN BR	1	
17	13	37458	LOCKWASHER, TIE-DOWN BR	.2	
18	11	32219	NUT, TIE-DOWN BRACKET SCF	1	
18	11	32219	NUT, TIE-DOWN BRACKET SCF	.2	
19	27	48818	GASKET, SPACER TO TIE-DOW	1.1	
20		54768	THERMOSTAT	1	
20		54775	THERMOSTAT	.1	
21		54764	SPACER, THERMOSTAT HOUS	1	
21		54771	SPACER, THERMOSTAT HOUS	.1	
22	27	33179	GASKET, THERMOSTAT HOUS	1.1	
23	32	54862A	HOSE, HEAT EXCHANGER TO	1	
23	32	54862A	HOSE, HEAT EXCHANGER TO	.1	
24	54	32780	CLAMP, HOSE ATTACHING	2.2	
25	32	35100A	HOSE, HEAT EXCHANGER TO	2	
25	32	35100A	HOSE, HEAT EXCHANGER TO	.2	