



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		36303A 2	HEAT EXCHANGER KIT (BASIC)	1..		
1		36303A 1	HEAT EXCHANGER ASSEMBLY	1..		
2	37	37390	DECAL, HEAT EXCHANGER	1..		
3		37344	CAP, PRESSURE - HEAT EXC	1..		
4	27	38033	GASKET, HEAT EXCHANGER	1..		
5	27	38034	GASKET, HEAT EXCHANGER	1..		
6	10	34354	SCREW, END CAP TO HEAT E	2..		
7	12	33181	WASHER, SEALING - END CA	2..		
8		36301	BRACKET, MOUNTING - HEAT I	1..		
9		36302	BRACKET, MOUNTING - HEAT I	1..		
10	10	20090	SCREW, HEAT EXCHANGER BR	4..		
11	11	25269	NUT, HEAT EXCHANGER BRAC	4..		
12	10	28464	SCREW, MOUNTING BRACKET	2..		
13	10	20359	SCREW, MOUNTING BRACKET	2..		
14	13	37459	LOCKWASHER, MOUNTING BR	4..		
15	12	20553	WASHER, MOUNTING BRACKE	4..		
16	32	35566	HOSE, HEAT EXCHANGER TO I	2..		
17	54	32780	CLAMP, HOSE TO HEAT EXCH/	4..		
18	22	36304	ELBOW, MANIFOLD ELBOW (10	2..		
19	32	36307	HOSE, WATER PUMP TO HEAT	1..		
20	54	32880	CLAMP, HOSE TO WATER PUM	2..		
21	54	32781	CLAMP, HOSE ASSEMBLY TO F	2..		
22	32	35568	HOSE, HEAT EXCHANGER TO I	1..		
23	54	32880	CLAMP, HOSE TO HEAT EXCH/	4..		
24	22	36305	ELBOW, EXHAUST ELBOW (90	2..		
25		36299	HOUSING, THERMOSTAT	1..		
26		35884	THERMOSTAT	1..		
27	27	33179	GASKET, THERMOSTAT HOUS	1..		
28	10	26632	SCREW, THERMOSTAT HOUSI	2..		
29		36300	TAB, THERMOSTAT HOUSING	1..		
30	54	32880	CLAMP, HOSE TO THERMOSTA	4..		
31	27	33173	GASKET, FACE PLATE TO EXH/	4..		
32		36309	PLATE, FACE - EXHAUST ELBO	2..		
33	10	24217	SCREW, EXHAUST ELBOW CLA	6..		
34	27	35671	GASKET, FACE PLATE TO UPPI	4..		
35		36310	PLATE, FACE - UPPER EXHAUS	2..		
36	10	21951	SCREW, UPPER EXHAUST ELE	6..		
37	11	25269	NUT, EXHAUST ELBOW CLAMP	6..		
--		36306A 1	FRESH WATER COOLING KIT (M	1..		
--		38731A 1	FRESH WATER COOLING KIT (M	1..		