


**BREAKDOWN OF WATER PUMP**



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		61651A 1	INSTALLATION KIT, FRESH WAT	1		
1	46	63450A 2	WATER PUMP ASSEMBLY, COP	1		
2	22	32802	PLUG, PIPE - DRAIN	1		
3		59155	COVER, WATER PUMP	1		
4	10	28635	SCREW, COVER TO WATER I	6		
5	25	59712	"O" RING, WATER PUMP COV	1		
6	19	59504	PLUG, IMPELLER	1		
7	47	59362A 1	IMPELLER	1		
8	28	56662	KEY, IMPELLER DRIVE	2		
9		59363A 1	CAM SEGMENT ASSEMBLY	1		
10	10	60777	SCREW, CAM SEGMENT ATT	1		
11		59503	WEAR PLATE, IMPELLER	1		
12	23	47511	SLEEVE, WATER PUMP	2		
13	26	23300	OIL SEAL, WATER PUMP SHA	2		
14	30	20861	BALL BEARING, WATER PUM	2		
15		59501	SHAFT, WATER PUMP	1		
16	53	23720	RING, SNAP - BALL BEARING	1		
17	26	59564	OIL SEAL, WATER PUMP SHA	1		
18		47530	HUB, WATER PUMP PULLEY	1		
19		59762	PULLEY, WATER PUMP	1		
20	10	47277	SCREW, WATER PUMP PULLE	4		
21	13	39107	LOCKWASHER, WATER PUMP	4		
22	57	60327	"V" BELT, WATER PUMP	1		
23		61859	BRACKET, ALTERNATOR	1		
24	32	54906	HOSE, SEA WATER PUMP TO I	1		
24	32	57230	HOSE, PUMP TO OIL COOLER I	1		
24	32	57231	HOSE - OIL COOLER TO HEAT E	1		
25	54	32780	CLAMP, HOSE TO SEA WATER	2		
26		49581	BRACKET, WATER PUMP TO A	1		
27	10	34354	SCREW, CLAMPING - WATER F	1		
28	13	35048	LOCKWASHER, WATER PUMP	3		
29	10	52409	SCREW, WATER PUMP BRACK	1		
30	12	20553	WASHER, WATER PUMP BRAC	1		
31	23	33186	BUSHING, WATER PUMP BRAC	1		
32	11	23161	NUT, WATER PUMP BRACKET	1		
33		61860	BRACE, WATER PUMP BRACK	1		
34	10	34353	SCREW, WATER PUMP BRACK	1		
35	11	28517	NUT, WATER PUMP BRACKET	1		
36	10	26632	SCREW, WATER PUMP BRACE	1		
37	12	34714	WASHER, WATER PUMP BRAC	1		