



TR/TRS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
--		55110A 1	POWER STEERING CYLINDER A	1		
1		57969A12	CYLINDER	1		
2		26059	CAP	1		
3	32	57633	TUBE, EXTENDING	1		
4	32	57634	TUBE, RETRACTING	1		
5		516458A1	VALVE	1		
6	22	67305	GREASE FITTING	2		
7	16	55109T	STUD	1		
8	10	37612	SCREW (1-1/4")	1		
9	13	35048	LOCKWASHER	1		
10	23	60652	SLEEVE	1		
11		64414	GUIDE	1		
12	23	60773	SLEEVE	1		
13		55110	ADAPTER (DUAL)	1		
14	13	76629	LOCKWASHER	1		
15	11	55111	NUT	1		
16	32	55112	TUBE	1		
17	12	37985	WASHER	2		
18	11	37987	NUT	2		
19		57286	BRACKET	1		
20	10	31832	SCREW (1")	2		
21	13	31848	LOCKWASHER	2		
22	10	57968	SCREW (3")	1		
23	13	35048	LOCKWASHER	1		
24	11	46335	NUT	1		
25	12	20959	WASHER	1		
26	11	28040	NUT	1		
27		57971	TUBE	1		
28	11	55983	JAM NUT	1		
29	24	78498	SPRING	1		
30		57970T	EXTENSION	1		
31		87854	ADAPTER	1		
32	17	52798	CLEVIS PIN	2		
33	18	46950	COTTER PIN	2		