

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	600	3292A 1	CONNECTING ROD ASSEMBLY	1		4
2	10	48031	SCREW, CONNE CTING ROD	2		
3	11	20061	NUT, CONNE CTING	2		
4	29	20046	NEEDLE BEARING, CRANKPIN	25		
5	29	20063	NEEDLE BEARING, PISTON PIN	22		
6	12	20064	WASHER, NEEDLE	2		

