



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
-		45194A26	OUTBOARD POWER TRIM ASSE	1		
56		76509A 3	SHOCK CYLINDER ASSEMBLY	2		
56A	22	74036	GREASE FITTING, SHOCK CY	2		
57	10	45265	SCREW, BLEED - SHOCK CYL	4		
58	25	45016	"O" RING, SHOCK CYLINDER	4		
59	10	45264	SCREW, SHOCK CYLINDER TO	2		
60	23	45280	SPACER, SHOCK CYLINDER - L	2		
61	23	45281	BUSHING, RUBBER - SHOCK C	2		
62		66084	BRACKET, MOUNTING - SHOCK	1		
63	10	45263	SCREW, MOUNTING BRACKET	2		
64	10	28009	BOLT, MOUNTING BRACKET TI	4		
65	12	28008	WASHER, MOUNTING BRACKE	4		
66	11	35304	NUT, MOUNTING BRAC KET BC	4		
67		45196A 2	BRACKET ASSEMBLY, MOUNTI	1		
68	26	70608	OIL SEAL, STARBOARD MOU	1		
69		45286	PLUNGER, LIMIT SWITCH ACTI	1		
70	24	45272	SPRING, TENSION - LIMIT SWI	1		
71	16	45282	STUD, MOUNTING BRACKET A	1		
72	13	26993	LOCKWASHER, MOUNTING BR	2		
73	11	20083	NUT, MOUNTING BRACKET TO	2		
74	10	45328	SCREW, SHOCK CYLINDER TO	2		
75	12	37807	WASHER, SHOCK CYLINDER S	1		
76	11	20696	NUT, SHOCK CYLINDER SCREW	2		
77	24	24390	SPRING, TENSION - ADJUSTIN	1		
78	16	21085	STUD, ADJUSTING - CUT-OUT	1		
79	11	45812	NUT, JAM -LIMIT SWITCH ADJL	1		
80		45508	CAM, LIMIT SWITCH ADJUSTIN	1		
81		45509	PLATE, RETAINING - LIMIT SW	1		
82	10	68513	SCREW, RETAINING PLATE AK	1		
83	13	26996	LOCKWASHER, RETAINING PL	1		
84		45326A 2	SWITCH ASSEMBLY, CUT-OUT	1		
85	23	45354	BUSHING, RUBBER - CUT-OU	1		
86	10	47255	SCREW, CUT-OUT LIMIT SWIT	2		
87		45287	COVER, LIMIT SWITCH	1		
88	27	45275	GASKET, LIMIT SWITCH COVER	1		
89	10	24942	SCREW, LIMIT SWITCH COVER	5		
90		45289	COVER, INLET - TRANSOM	1		
91	27	45274	GASKET, INLET COVER	1		
92	25	45507	GROMMET, RUBBER - INLET C	1		
93	10	32866	SCREW, INLET COVER TO BOA	4		