



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		76509A12	OUTBOARD POWER TRIM ASSE	1		
56		76509A 3	TRIM CYLINDER ASSEMBLY	2		
57	22	74036	GREASE FITTING, TRIM CYLI	2		
58	10	45265	SCREW, BLEED - TRIM CYLIN	4		
59	25	45016	"O" RING, TRIM CYLINDER B	4		
60	10	45264	SCREW, TRIM CYLINDER TO L	2		
61	12	28421	WASHER, TRIM CYLINDER BOI	4		
62	23	45280	SPACER, TRIM CYLINDER - LO	2		
63	23	45281	BUSHING, RUBBER - TRIM CYL	2		
64		89108A 3	BRACKET, MOUNTING - TRIM C	1		
65	26	70608	OIL SEAL, PORT MOUNTING	1		
66		89290	PLUNGER, LIMIT SWITCH ACTI	1		
67	24	45272	SPRING, TENSION - LIMIT SWI	1		
68	16	45282	STUD, MOUNTING BRACKET A	1		
69	13	26993	LOCKWASHER, MOUNTING BR	2		
70	11	20083	NUT, MOUNTING BRACKET TO	2		
71	10	45263	SCREW, MOUNTING BRACKET	2		
72	10	68298	BOLT, MOUNTING BRACKET TI	4		
73	12	68410	WASHER, MOUNTING BRACKE	4		
74	11	68411	NUT, MOUNTING BRACKET BO	4		
75		89111	BRACKET, MOUNTING - TRIM C	1		
76	10	45328	SCREW, SHOCK CYLINDER TO	2		
77	12	37807	WASHER, SHOCK CYLINDER S	1		
78	11	20696	NUT, SHOCK CYLINDER SCREW	2		
79	24	24390	SPRING, TENSION - ADJUSTIN	1		
80	16	21085	STUD, ADJUSTING - CUT-OUT	1		
81	11	45812	NUT, JAM - LIMIT SWITCH ADJI	1		
82		45508	CAM, LIMIT SWITCH ADJUSTIN	1		
83		86967	PLATE, RETAINING - LIMIT SW	1		
84	10	68513	SCREW, RETAINING PLATE AN	1		
85	13	26396	LOCKWASHER, RETAINING PL	1		
86		45326A 2	SWITCH ASSEMBLY, CUT -OUT	1		
87	23	45354	BUSHING, RUBBER - CUT-OU	1		
88	10	47255	SCREW, CUT-OUT LIMIT SWIT	2		
89		89272	COVER, LIMIT SWITCH	1		
90	27	89273	GASKET, LIMIT SWITCH COVER	1		
91	10	34994	SCREW, LIMIT SWITCH COVER	4		
92	12	72761	WASHER, LIMIT SWITCH COVE	4		
93		87774A 1	COVER, INLET - TRANSOM	1		
94	27	87775	GASKET, INLET COVER	1		