



15107

				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
-		845313A 1	INDICATOR ASSEMBLY, Two Cat	1		
-		845313A 2	INDICATOR ASSEMBLY, Two Cat	1		
-		845313A 6	INDICATOR ASSEMBLY, Two Cat	1		
-		845314A 1	INDICATOR ASSEMBLY, Two Cat	1		
-		845314A 2	INDICATOR ASSEMBLY, Two Cat	1		
-		845314A 6	INDICATOR ASSEMBLY, Two Cat	1		
1		845468A 1	BEZEL ASSEMBLY, Top Entry (B	1		
1		845468A 2	BEZEL ASSEMBLY, Top Entry (V	1		
1		845468A 3	BEZEL ASSEMBLY, Top Entry (V	1		
1		845469A 1	BEZEL ASSEMBLY, Bottom Entry	1		
1		845469A 2	BEZEL ASSEMBLY, Bottom Entry	1		
1		845469A 3	BEZEL ASSEMBLY, Bottom Entry	1		
2		845315 1	BEZEL (Black)	1		
2		845315 2	BEZEL (White)	1		
3		845319	LENS, View	1		
4		845399	LENS (2 Drives or Tabs/Trim D	1		
4		849512	LENS (2 Drives or Tabs/Trim D	1		
5		845321	LENS (2 Drives or Tabs/Trim U	1		
5		849513	LENS (2 Drives or Tabs/Trim D	1		
6		845320	PLATE, Pointer Support	1		
7	16	845019	STUD, (.250-20 x 2.750)	4		
8	23	847340	SPACER	4		
9	11	64015	NUT, (.250-20)	4		
10	12	35044	WASHER, (.281 x .625 x .065 - S	4		
11	11	814101	NUT, (.250-20)	4		
12		847336A 1	BRACKET ASSEMBLY	1		
13		847336	BRACKET	1		
14		845304	LIGHT ASSEMBLY	3		
15	10	845301	SCREW, (#8-32 X .750) Brass	2		
16	12	847341	WASHER, Nylon	4		
17	11	26419	NUT, (#8-32)	4		
18	13	845302	LOCKWASHER, (#8 Internal)	2		
19	10	32228	SCREW, (#10-32 x .625)	2		
20		845470	BAR, Cable Lock	1		
21	11	34059	NUT, (#10-32)	2		
22		845014	POINTER, (Short .73) (White)	2		
22		849584	POINTER, (Short .73) (Red)	2		
22		845150	POINTER, (Long 1.17) (White)	2		
22		849583	POINTER, (Long 1.17) (Red)	2		
23	24	845016	SPRING, (1.00 Inch)	2		