



1736

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		827270A41	REMOTE CONTROL	1	(Non Trim)	14
-		827270A42	PANEL MOUNT REMOTE CONTR	1	(Outboard)	14
-		827270A43	PANEL MOUNT REMOTE CONTR	1	(Mercruiser)	14
-		827270A45	PANEL MOUNT REMOTE CONTR	1	(Bayliner Non Trim)	14
-		827270A46	PANEL MOUNT REMOTE CONTR	1	(Bayliner Outboard)	14
-		827270A47	PANEL MOUNT REMOTE CONTR	1	(Bayliner Mercruiser)	14
-		827270A48	PANEL MOUNT REMOTE CONTR	1	(Sea Ray Outboard)	14
-		827270A49	PANEL MOUNT REMOTE CONTR	1	(Sea Ray Mercruiser)	14
-		827270A50	PANEL MOUNT REMOTE CONTR	1	(Wellcraft Outboard)	
-		827270A51	PANEL MOUNT REMOTE CONTR	1	(Wellcraft Mercruiser)	
1		817257	GRIP	1	(Non Trim and Outboard)	
2		817258	GRIP	1	(Mercruiser)	
3	87	18286A31	SWITCH ASSEMBLY, Trim/Traile	1	(Outboard)	
3	87	18286A32	SWITCH ASSEMBLY, Trim/Traile	1	(Bayliner Outboard)	
4	87	18286A33	SWITCH ASSEMBLY, Trim/Traile	1	(Mercruiser)	
5	24	16924	SPRING	1		
6		822212	BUTTON, Throttle Only	1		
7	10	822213	BOLT, Locking, Special	1		
8		822211T 1	HANDLE, Control, Black	1		
9	10	58376	SCREW, (.164-18 x .375)	1		
10		817259	RELEASE, Shift	1		
11	12	28001	WASHER, (.188 x .438 x .049)	1		
12	10	40056 85	SCREW, (M4 x 10)	1		
13	37	827289 14	DECAL, Bezel	1	(Starboard)	
13	37	827289 15	DECAL, Bezel	1	(Port)	
14	23	822980	BUSHING, Firm, White	1		
15	87	13398 2	STOP SWITCH	1	(Outboard)	
15	87	13398 3	STOP SWITCH	1	(Mercruiser)	
16	10	19923088	SCREW, (.250-20 x .875)	3		
17		822216T 1	BEZEL	1	(Black) (Design I)	
17		881173T 1	BEZEL	1	(Black) (Design II)	
18		12044 1	RETAINER	1		
19	12	69057	WASHER, (.281 x .734 x .063)	3		
20	11	814101	NUT, (.250-20)	3		
21	10	822981 1	SET SCREW, (.250-20 x .187), Fi	1		
22	10	822214	SCREW, (.250-20 x 1.750)	3		
23		15920Q54	LANYARD ASSEMBLY	1		
24		817697	PLUG, Stop Switch Hole	1	(Non Trim)	
25	37	827288 1	DECAL, Hub	1		
26		17192	PLUG, Stop Switch Hole	1	(Wellcraft Mercruiser)	