



15583

Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|-----------|------------------------------|-----|-----------------------------------|----------|
| - | | 88150A40 | REMOTE CONTROL | 1 | (Non Trim) | 10 |
| - | | 88150A41 | REMOTE CONTROL | 1 | (Outboard) | 10 |
| - | | 88150A42 | REMOTE CONTROL | 1 | (Mercruiser) | 10 |
| - | | 88150A43 | REMOTE CONTROL | 1 | (Bayliner Non Trim) | 10 |
| - | | 88150A44 | REMOTE CONTROL | 1 | (Bayliner Outboard) | 10 |
| - | | 88150A45 | REMOTE CONTROL | 1 | (Mercruiser) | 10 |
| - | | 88150A47 | REMOTE CONTROL | 1 | (Sea Ray Outboard) | 10 |
| - | | 88150A48 | REMOTE CONTROL | 1 | (Sea Ray Mercruiser) | 10 |
| 1 | | 824023A 1 | HANDLE ASSEMBLY | 1 | (Non Trim) (High Gloss) | |
| 1 | | 824023A 6 | HANDLE ASSEMBLY | 1 | (Outboard and Mercruiser) (High G | |
| 1 | | 824023A 8 | HANDLE ASSEMBLY | 1 | (Non Trim) (Low Gloss) | |
| 1 | | 824023A 9 | HANDLE ASSEMBLY | 1 | (Outboard and Mercruiser) (Low GI | |
| 2 | | 824024 | RELEASE, Neutral Lock | 1 | | |
| 3 | 24 | 85010 | SPRING | 1 | | |
| 4 | | 824025 | COVER, Handle | 1 | (High Gloss) | |
| 4 | | 824025 1 | COVER, Handle | 1 | (Low Gloss) | |
| 5 | 87 | 18286A41 | SWITCH ASSEMBLY | 1 | (Outboard and Mercruiser) (Low GI | |
| 6 | | 824027 1 | CAP, Switch | 1 | (Low Gloss) | |
| 6 | | 824027 2 | CAP, Switch | 1 | (High Gloss) | |
| 7 | | 815865 | PLUG, Grip | 1 | (Non Trim) (High Gloss) | |
| 7 | | 815865 1 | PLUG, Grip | 1 | (Non Trim) (Low Gloss) | |
| 8 | 10 | 826132 | SCREW, (#12 x .875) | 1 | (824023A1 or A6 Handle Assembly | |
| 8 | 10 | 40019108 | SCREW, (M5 x 20) | 1 | (824023A1 or A6 Handle Assembly | |
| 9 | | 824026 | BUTTON, Throttle Only | 1 | | |
| 10 | 54 | 816311T | CABLE TIE, (8.00 Inches) | 1 | | |
| 11 | 23 | 822980 | BUSHING, Firm, White | 1 | | |
| 12 | | 824019A 1 | COVER ASSEMBLY, Top | 1 | (High Gloss) | |
| 12 | | 824019A 2 | COVER ASSEMBLY, Top | 1 | (Low Gloss) | |
| 13 | 37 | 824655 | DECAL, Bezel | 1 | (Starboard) | |
| 13 | 37 | 824655 1 | DECAL, Bezel | 1 | (Port) | |
| 14 | 10 | 822981 1 | SET SCREW, (.250-20 x .187) | 1 | | |
| 15 | | 824020A 1 | COVER ASSEMBLY, Bottom | 1 | (Mercruiser) (High Gloss) | |
| 15 | | 824020A 2 | COVER ASSEMBLY, Bottom | 1 | (Mercruiser) (Low Gloss) | |
| 16 | 37 | 824656 | DECAL, Bottom Cover | 1 | | |
| 17 | | 824021A 1 | COVER ASSEMBLY, Bottom | 1 | (Outboard and Non Trim) (High Glc | |
| 17 | | 824021A 2 | COVER ASSEMBLY, Bottom | 1 | (Outboard and Non Trim) (Low Glo | |
| 18 | 37 | 824656 | DECAL, Bottom Cover | 1 | | |
| 19 | | 824018 1 | BEZEL | 1 | | |
| 20 | 10 | 822214 | SCREW, (.250-20 x 1.750) | 3 | (Bezel to Panel) | |
| 21 | 12 | 69057 | WASHER, (.281 x .734 x .063) | 3 | | |