



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		827270A52	REMOTE CONTROL	1	(Maxum Outboard)	14
-		827270A53	REMOTE CONTROL	1	(Maxum Mercruiser)	14
-		827270A54	REMOTE CONTROL	1	(Outboard)	14
-		827270A55	REMOTE CONTROL	1	(Mercruiser)	14
1		817257	GRIP	1	(All Outboard Models)	
2		817258	GRIP	1	(All Mercruiser Models)	
3	87	18286A32	SWITCH ASSEMBLY, Trim/Traile	1	(All Outboard Models)	
4	87	18286A33	SWITCH ASSEMBLY, Trim/Traile	1	(All Mercruiser Models)	
5	24	16924	SPRING	1		
6		822212	BUTTON, Throttle Only	1		
7	10	822213	BOLT, Locking, Special	1		
8		822211T	HANDLE, Control	1	(Painted, Satin Taupe)	
9	10	58376	SCREW, (.164-18 x .375)	1		
10		817259	RELEASE, Shift	1		
11	12	28001	WASHER, (.188 x .438 x .049)	1		
12	10	40056	SCREW, (M4 x 10)	1		
13	37	827289	DECAL, Bezel	1	(Outboard and Mercruiser)	
13	37	856665	DECAL, Bezel	1	(Maxum Outboard and Mercruiser)	
14	23	822980	BUSHING, Firm	1		
15	37	827288	DECAL, Hub	1	(Outboard and Mercruiser)	
15	37	856666	DECAL, Hub	1	(Maxum Outboard and Mercruiser)	
16	87	13398	STOP SWITCH	1	(All Outboard Models)	
16	87	13398	STOP SWITCH	1	(All Mercruiser Models)	
17	10	19923088	SCREW, (.250-20 x .875)	3		
18		822216T	BEZEL	1	(Painted, Satin Taupe) (Design I)	
18		881173T	BEZEL	1	(Painted, Satin Taupe) (Design II)	
19		12044	RETAINER	1		
20	12	69057	WASHER, (.281 x .734 x .063)	3		
21	11	814101	NUT, (.250-20)	3		
22	10	822981	SET SCREW, (.250-20 x .187), Fi	1		
23	10	822214	SCREW, (.250-20 x 1.750)	3		
24		15920Q54	LANYARD ASSEMBLY	1		
25	54	816311T	CABLE TIE, (8.00 Inches)	1		