



15587

Parts List

| Ref | Class | Part      | Description                  | Qty | Comment                   | Footnote |
|-----|-------|-----------|------------------------------|-----|---------------------------|----------|
| -   |       | 88688A60  | REMOTE CONTROL               | 1   | (Non Trim)                | 13       |
| -   |       | 88688A62  | REMOTE CONTROL               | 1   | (Outboard)                | 13       |
| -   |       | 88688A64  | REMOTE CONTROL               | 1   | (Mercruiser)              | 13       |
| 1   |       | 824044A 3 | HANDLE ASSEMBLY              | 1   | (Outboard and Mercruiser) |          |
| 1   |       | 824044A 1 | HANDLE ASSEMBLY              | 1   | (Non Trim)                |          |
| 2   |       | 824042    | GRIP, Upper                  | 1   | (Outboard and Mercruiser) |          |
| 3   |       | 824041    | GRIP, Upper                  | 1   | (Non Trim)                |          |
| 4   | 10    | 72415     | SCREW, (#10-16 x 1.00)       | 2   |                           |          |
| 5   | 87    | 18286A41  | SWITCH ASSEMBLY              | 1   | (Outboard and Mercruiser) |          |
| 6   |       | 824048    | CAP                          | 1   | (Outboard and Mercruiser) |          |
| 7   |       | 824028    | CARRIER, Switch              | 1   | (Outboard and Mercruiser) |          |
| 8   | 23    | 822980 2  | BUSHING, Flex, Black         | 1   |                           |          |
| 9   | 10    | 822981 1  | SET SCREW, (.250-20 x .187)  | 1   |                           |          |
| 10  |       | 824045A 1 | BUTTON ASSEMBLY, Throttle    | 1   |                           |          |
| 11  |       | 824033A 4 | COVER ASSEMBLY               | 1   |                           |          |
| 12  | 37    | 830755 1  | DECAL                        | 1   |                           |          |
| 13  |       | 824035A 1 | BASE ASSEMBLY                | 1   |                           |          |
| 14  | 27    | 824030 1  | GASKET                       | 1   |                           |          |
| 15  |       | 824031    | BRACKET, Mounting            | 2   |                           |          |
| 16  | 10    | 66687     | SCREW, (#10-32 x 1.50)       | 4   |                           |          |
| 17  | 11    | 42290     | WELL NUT, (#10-32)           | 4   |                           |          |
| 18  | 10    | 89044     | SCREW, (#10-32 x 2.25)       | 2   |                           |          |
| 19  | 11    | 29488     | NUT, (#10-32)                | 2   |                           |          |
| 20  |       | 822434    | ANCHOR, Cable Tie            | 1   |                           |          |
| 21  | 54    | 816311T   | CABLE TIE, (8.00 Inches)     | 2   |                           |          |
| 22  |       | 76424     | BRACKET, Switch Mounting     | 1   | (Mercruiser)              |          |
| 23  |       | 85218A 5  | PLATE ASSEMBLY, Switch Moun  | 1   | (Mercruiser)              |          |
| 24  |       | 49440     | NUT, (.468-32)               | 1   | (Mercruiser)              |          |
| 25  | 16    | 55422     | STUD, (#10-32 x 2.00)        | 2   | (Mercruiser)              |          |
| 26  | 12    | 24676     | WASHER, (.200 x .440 x .032) | 2   | (Mercruiser)              |          |
| 27  | 11    | 68219     | NUT, (#10-32)                | 2   | (Mercruiser)              |          |
| 28  | 84    | 824783A 1 | HARNES ASSEMBLY, Extensio    | 1   | (Outboard)                |          |
| 29  | 84    | 824783A 6 | HARNES ASSEMBLY, Extensio    | 1   | (Mercruiser)              |          |