



2415

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		883709A01	REMOTE CONTROL, (Non Trim)	1	(Outboard)/(Sterndrive)	
-		883709A02	REMOTE CONTROL	1	(Outboard)	
-		883709A03	REMOTE CONTROL	1	(Mercruiser)	
-		883709A04	REMOTE CONTROL, (Non Trim)	1	(MIE./Inboard)	
1		858666T12	HANDLE/BEZEL KIT	1	(Outboard)	
1		858666T13	HANDLE/BEZEL KIT	1	(Mercruiser)	
1		858666T14	HANDLE/BEZEL KIT, Non Trim	1		
1		898840T02	HANDLE ASSEMBLY (Outboard)	1		
1		898840T03	HANDLE ASSEMBLY (Mercruiser)	1		
1		898840T04	HANDLE ASSEMBLY, Non Trim	1		
2	87	859032T 1	SWITCH/HARNESS ASSEMBL	1	(Outboard)	
3	87	858679T 1	SWITCH/HARNESS ASSEMBL	1	(Mercruiser)	
4	10	858687	SCREW	5		
5	10	858686	SCREW	2		
6		892959T	BEZEL ASSEMBLY, With Inset	1		
7		822212	BUTTON, Throttle Only	1		
8	10	822213 1	BOLT, Locking (Special)	1		
9	23	859016	BUSHING, Handle	1		
10	10	858660	SCREW, Bezel	2		
11		858681	COVER, (Dark Grey), Front (Black)	1		
12		858682	COVER, (Dark Grey), Back (Black)	1		
NS		880861A 1	COVER SET, Front and Back	OPT	(Woodgrain Style)	
13		12044 1	RETAINER	1		
14	10	19923062	SCREW, (.250-20 x .625)	3		
15	87	13398 2	STOP SWITCH	1	(Outboard)	
15	87	13398 3	STOP SWITCH, Stop	1	(Mercruiser)	
16		<a href="#">15920Q54</a>	LANYARD ASSEMBLY	1		
17	10	859031	SCREW, (.250-20 x 1.50)	3		
18	12	859664	WASHER	3		
19	11	826708 8	NUT, (.250-20)	3		
20	84	824783A11	HARNESS ADAPTER ASSEMBL	1	(Outboard)	
21	84	817659A 1	HARNESS ASSEMBLY, Trim - 16 F	1	(Mercruiser) (Not included in Remc	
22	84	881125A 1	HARNESS ASSEMBLY, Trim - 24 F	1	(Mercruiser) (Not included in Remc	
NS		883719A	CABLE ASSEMBLY, Throttle/Shift	AR	(See Accessories Guide for correc	
NS		883720A	CABLE ASSEMBLY, Throttle/Shift	AR	(See Accessories Guide for correc	
NS	91	892535A01	INDICATOR TOOL, Shift Load	1	(Use with MPC 4000 (Gen II) Pane	