



(BOTTOM MOUNTING)

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		35158A 1	REMOTE CONTROL HSTALLATIC	1		
1		35158A 2	REMOTE CONTROL HSTALLATIC	1		
2	10	28424	SCREW, SPACER TO BOAT	2	2,2	