



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		37620A 8	POWER STEERING PUMP MOUN	1,		
-		37620A 9	POWER STEERING PUMP MOUN	,1,		
-		37620A13	POWER STEERING PUMP MOUN	,1		
1	57	53215	"V" BELT, HYDRAULIC PUMP C	1,1,		
1	57	49756	"V" BELT, HYDRAULIC PUMP C	,1		
2	10	37558	SCREW, BRACE TO ALTERNAT	1,1,1		
3	13	39107	LOCKWASHER, ALTERNATOR	1,1,1		
4	12	20331	WASHER, ALTERNATOR BRAC	1,1,1		
5	23	36534	SPACER, ALTERNATOR BRACE	1,1,1		
6		48086A 1	PULLEY ASSEMBLY, CRANKSH	1,1		
6		48085A 1	PULLEY ASSEMBLY, CRANKSH	,1,		
7	10	32515	SCREW, PULLEY TO CRANKS	1,1		
8	10	48308	SCREW, PULLEY TO DAMPEF	3,3		
8	10	48989	SCREW, PULLEY TO DAMPEF	,3,		
9	13	37459	LOCKWASHER, PULLEY SCR	3,3,3		
10		49770	OIL COOLER	1,1,1		
11	22	37760	ELBOW, RETURN HOSE TO OIL	2,2,2		
12	32	49745	HOSE, OIL COOLER TO WATER	1,		
12	32	49763	HOSE, OIL COOLER TO WATER	,1,		
13	54	32780	CLAMP, HOSE TO OIL COOLER	2,2,2		
14	54	32781	CLAMP, OIL COOLER TO MOUN	2,2,2		
15		49748A 1	BRACKET ASSEMBLY, OIL COO	1,1,1		
16	10	27165	SCREW, OIL COOLER BRACKE	1,1,1		
17	11	52412	NUT, OIL COOLER BRACKET SI	1,1,1		
18		49735	BRACKET, OIL COOLER MOUN	1,1,1		
19	10	48424	SCREW, MOUNT BRACKET TO	2,2,2		
20	13	37459	LOCKWASHER, MOUNT BRACK	2,2,2		
21	23	36365	SPACER, MOUNT BRACKET SC	2,2,2		
22	32	52406	HOSE, OIL COOLER TO HYDRA	1,1		
22	32	52480	HOSE, OIL COOLER TO HYDRA	,1,		
23	54	37295	CLAMP, HOSE TO OIL COOLER	2,2,2		
24		49683	BRACKET, HYDRAULIC PUMP	1,		
24		49684	BRACKET, HYDRAULIC PUMP	,1,		
24		57611	BRACKET, HYDRAULIC PUMP	,1		
25	10	37612	SCREW, HYDRAULIC PUMP MC	2,2		
25	10	47651	SCREW, HYDRAULIC PUMP MC	,1,		
25	10	47462	SCREW, HYDRAULIC PUMP MC	,1,		
26	13	37459	LOCKWASHER, MOUNTING BR	2,2		
26	13	32993	LOCKWASHER, MOUNTING BR	,2,		
27	12	34664	WASHER, MOUNTING BRACKE	2,2		