



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		66800A 2	RACK AND PINION ASSEMBLY	1		
1		66800	HOUSING, RACK	1		
2	22	26000	GREASE FITTING	1		
3		29359	LUBRICAP, GREASE FITTING	1		
4		66799	HOUSING, RACK MOUNT	1		
5	10	69086	SCREW, RACK MOUNT HOUSI	4		
6	12	29245	WASHER, RACK MOUNT HOUS	4		
7	11	20361	NUT, RACK MOUNT HOUSING	4		
8		66801	BRACKET, STOP	1		
9	10	60300	SCREW, STOP BRACKET TO R.	2		
10	11	20361	NUT, STOP BRACKET TO RACK	2		
11		66802	RACK	1		
12		66803	BUSHING, RACK	1		
13		66804	GUIDE, RACK	2		
14		66805	MOUNT, STEERING CABLE AT	1		
15	10	21937	SCREW, MOUNT TO RACK HOI	2		
16	12	29245	WASHER, MOUNT TO RACK HI	2		
17	11	20361	NUT, MOUNT TO RACK HOUSI	2		
18		25898	PINION	1		
19	23	25901	BUSHING, SPLINED NYLON - P	2		
20	12	25897	WASHER, PINION SECURING	1		
21		66806	COVER, RACK HOUSING	1		
22	11	20088	NUT, STEERING CABLE TO RA	2		
23	11	25899	NUT, JAM STEERING CABLE TC	1		