



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		42349A 2	SHIFT ACTUATOR ASSEMBLY	1		2
2		NLA	ARMATURE	1		3
3		392-4960	SPRING SET, BRUSH	1		
4		392-4955	HEAD ASSEMBLY, COMMUTAT	1		
5		392-4956	BRUSH SET	1		
6		392-4962	THRU BOLT	2		
7		NSS	FIELD COIL ASSEMBLY	1		4
8		NSS	CRANK ARM ASSEMBLY	1	PRESTOLITE #ETT-1056	4
9		NLA	HEAD ASSEMBLY, DRIVE END	1		3
10		NLA	SCREW AND DISC PACKAGE	1		3
11		392-4952	GEAR AND GASKET PACKAGE	1		
12		392-4953	GASKET	1		
13		NLA	PLATE	2		3
14		42528A 6	SWITCH PLATE AND GASKET F	1		
15		392-4953	GASKET	1		
16	84	62995A 1	HARNES ASSEMBLY (3 WIRE	1		