



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		39128A	RIDE-GUIDE ATTACHMENT KIT (1,		
-		38619A	RIDE-GUIDE ATTACHMENT KIT (,1		
1		27973	COUPLING, ADJUSTING - DUAL	1,1		
2	11	22496	NUT, ADJUST COUPLING	1,1		
3		39129A	EYE ASSEMBLY, DUAL CONTR	1,		
3		38624A	EYE ASSEMBLY, DUAL CONTR	,1		
3		39130A	EYE ASSEMBLY, DUAL CONTR	1,		
3		38625A	EYE ASSEMBLY, DUAL CONTR	,1		
4	10	49220	SCREW, PIVOT CONTROL ENG	2,2		
5		29698	BALL, STEEL - PIVOT SCREW	3,3		
6	12	29330	WASHER, NYLON - PIVOT SCR	3,3		
7	12	25909	WASHER, PIVOT SCREW	4,		
7	12	25970	WASHER, PIVOT SCREW	,6		
8	24	20510	SPRING, PIVOT SCREW	2,2		
9	23	25915	BUSHING, RUBBER - PIVOT SC	2,2		
10	23	36534	SPACER, PIVOT SCREW	1,1		
11	11	20509	NUT, PIVOT SCREW	1,1		
12		66741	LINK ROD, STEERING	1,1		
13	23	66751	SPACER, STEERING LINK ROD	,1		
14	12	20086	WASHER, STEERING LINK RO	2,		
14	12	34931	WASHER, STEERING LINK RO	,2		
15	11	20509	NUT, STEERING LINK ROD	2,2		
16		30352A	COUPLER ASSEMBLY, EXTENSIC	AR,AR		
17	13	30381	LOCKWASHER, COUPLER ASS	2,2		
18		30351A	BAR ASSEMBLY (4" EXTENSION)	AR,AR		
19	13	30381	LOCKWASHER, EXTENSION B	1,1		
20		30353	ROD, LINK (16" EXTENSION)	AR,AR		