



| Parts List | | | | | | |
|------------|-------|--------|----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 76130A | STEERING WHEEL ASSEMBLY, X | 1 | | |
| 2 | | 76125 | HUB, STEERING WHEEL | 1 | | |
| 3 | 10 | 26065 | SCREW, STEERING WHEEL TC | 3 | | |
| 4 | 12 | 20084 | WASHER, STEERING WHEEL T | 3 | | |
| 5 | 11 | 35814 | NUT, STEERING WHEEL TO HI | 3 | | |
| 6 | | 76126 | CAP, TOP - STEERING WHEEL | 1 | | |
| 7 | 10 | 56027 | SCREW, HUB TO STEERING W | 3 | | |
| 8 | | 57914A | DRIVE ASSEMBLY, STEERING | 1 | | |
| 9 | | 57913 | LENS, STEERING WHEEL | 1 | | |