



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		38047A11	UNIVERSAL RIDE-GUIDE ATTACHING KIT	1		
1		56035	BRACKET, PIVOT BLOCK TO BRACKET	1		
2	10	26483	SCREW, TRANSOM BRACKET	2		
3	13	26993	LOCKWASHER, TRANSOM BRACKET	2		
4	11	21908	NUT, TRANSOM BRACKET SCREW	2		
5	10	29222	SCREW, TRANSOM BRACKET	1		
6	23	28343	SPACER, PIVOT - TRANSOM BRACKET	1		
7		28190	BLOCK, PIVOT	1		
8	12	21040	WASHER, TRANSOM BRACKET	1		
9	11	20509	NUT, TRANSOM BRACKET TO YOK	1		
10	10	56393	SCREW, PIVOT BLOCK TO YOK	1		
11	12	22248	WASHER, PIVOT BLOCK SCREW	2		
12		30700	YOKE, PIVOT BLOCK	1		
13	11	20696	NUT, PIVOT BLOCK SCREW	1		
14	32	35015	TUBE, CABLE GUIDE	1		
15	11	37984	NUT, ADJUSTING - CABLE GUIDE	2		
16		70599A	CLEVIS, STEERING CABLE	1		
17	10	35871	SCREW, STEERING CABLE CLEVIS	2		
18	12	20553	WASHER, STEERING CABLE CLEVIS	1		
19	11	20509	NUT, STEERING CABLE CLEVIS	2		
20	12	28105	WASHER, STEERING ARM SCREW	2		
23	10	49220	SCREW, STEERING ARM TO STEERING ARM	1		
24	11	20509	NUT, STEERING ARM SCREW	1		