



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|--------|----------------------------|-----|--------------|----------|
| - | | 14144A | ROTARY STEERING/TILT SYSTE | 1 | SEE FOOTNOTE | 2,3 |
| 1 | | 11110A | CABLE | 1 | SEE FOOTNOTE | 2,3 |
| 2 | 28 | 91800 | KEY | 1 | | |
| 3 | 11 | 20220 | NUT | 1 | | |
| 4 | 10 | 44416 | SET SCREW | 1 | | |
| 5 | | 14119T | POST | 1 | | |
| 6 | | N.S.S. | SCREW (1-1/2") | 2 | | 7 |
| 7 | 11 | 22024 | LOCK NUT | 2 | | |
| 8 | 23 | 48237 | BUSHING (3/8") | 2 | | |
| 9 | | N.S.S. | QUAD RING | 2 | | 7 |
| 10 | | 48224 | LEVER | 1 | | |
| 11 | | N.S.S. | DETENT PIN | 1 | | 7 |
| 12 | 16 | 29208 | STUD | 4 | | |
| 13 | 12 | 26825 | WASHER | 4 | | |
| 14 | 11 | 35814 | NUT | 4 | | |
| 15 | | N.S.S. | SCREW (1-1/4") | 3 | | 7 |
| 16 | 17 | 20009 | PIN | 1 | | |
| 17 | 24 | 35227 | SPRING | 1 | | |
| 18 | 19 | 20011 | PLUG | 1 | | |
| 19 | | N.S.S. | SPACER | 1 | | 7 |
| 20 | | N.S.S. | SPRING | 1 | | 7 |
| 21 | 23 | 28104 | BUSHING | 1 | | |