



5608

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		846860T 1	PUMP ASSEMBLY, Trim	1		
2		846859A 1	PUMP ASSEMBLY, Hydraulic	1	(See Hydraulic Pump Components	
3	22	77366	FITTING	2		
4	85	843809	BOOT (Solenoid To Pump Term	2		
5	37	847313	DECAL	1		
6	10	844430	SCREW, (.250-20 x 3.00)	2		
7		844407	BRACKET, Pump Mounting	1		
8		846866	BRACE, Hydraulic Pump	1		
9	11	846869	NUT, (.375-16)	2		
10	10	57807	SCREW, (#10-16 x .750)	2		
11	10	844417	SCREW, (.375-16 x .875)	4		
12		846850 1	PLATE, Pump Mounting	1		
13	89	846070	SOLENOID	2		
14	10	73286	SCREW, (.250-20 x .500)	3		
15	12	23243	WASHER, (.260 x .562 x .040 Br	4		
16	11	814101	NUT, (.250-20)	4		
17	11	846115	NUT, (#8-32)	4		
18	10	845856	SCREW, (.312-18 x .750)	1		
19		846124	STRAP	1		
20	11	846127	NUT, (.312-18 Brass)	1		
21	11	846128	NUT, (.312-18 SS)	1		
22	84	846134A 1	WIRE ASSEMBLY, Jumper	1		
23	85	843809	BOOT	2		
24	84	846160A 2	HARNES ASSEMBLY, Wiring	1		
25	89	846159	FUSE, (10 AMP)	1		