



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		36065A 2	FULL POWER TILT USE WITH MI	1,		
-		36065A 4	FULL POWER TILT USE WITH MI	1,		
-		36065A 3	FULL POWER TILT USE WITH MI	1,		
-		34901A 2	HYDRAULIC PUMP AND VALVE	1,1,1		
1		34901	HYDRAULIC PUMP ASSEMBL	1,1,1		
2	37	35520	DECAL, HYDRAULIC PUMP	1,1,1		
3	22	36567	ELBOW VENT NIPPLE TO HY	1,1,1		
4	22	35275	NIPPLE, VENT - HYDRAULIC	1,1,1		
5	22	35271	COUPLING VENT NIPPLE	1,1,1		
6		35303	COVER, VENT NIPPLE COUPL	1,1,1		
7		29256	SCREW, HYDRAULIC PUMP T	3,3,3		
8	54	35260	CLAMP, HYDRAULIC PUMP H	1,1,1		
9	10	29831	SCREW HVDRALIC PUMP H	1,1,1		
10	12	29245	WASHER, HYDRAULIC PUMF	1,1,1		
11		35080	BRACKET MOUNTING - HYDF	1,1,1		
12	10	35263	BOLT MOUNTING BRACKET T	3,3,3		
13	11	35304	NUT, MOUNTING BRACKET T	3,3,3		
14		36074A 1	VALVE ASSEMBLY HYDRAUL	1,1,1		
15		36075	TUBING ASSEMBLF, VALVE	1,1,1		
16	22	21290	PLUG, PIPE - VALVE BODY I	1,1,1		
L7	25	21706	"O"RING VALVE TO HYDRA	1,1,1		
L8		35160A 1	CAP ASSEMBLY, HYDRAUL	1,1,1		
19	25	26855	"O"RING HYDRAULIC VAL	1,1,1		
20	10	35383	SCREW, VALVE ASSEMBLY	2,2,2		
21	22	35268	PLUG PIPE - VALVE ASSEM	1,1,1		
22		35064A 1	PISTON ASSEMBLY LOW PI	1,1,1		
23	25	22762	"O" RING LOW PRESSUR	1,1,1		
24		35070A 1	PISTON ASSEMBLY, HIGH F	1,1,1		
25	25	35276	"O" RING, HIGH PRESSUR	1,1,1		
26	25	23373	"O" RING HIGH PRESSUR	1,1,1		
27	11	35258	NUT, JAM - HIGH PRESSUR	1,1,1		
28	22	3525	NIPPLE COUPLER TO HIGH	1,1,1		
29	10	35305	SCREW, VALVE ASSEMBLY T	3,3,3		
30	11	35307	NUT, VALVE ASSEMBLY TO	3,3,3		
31	22	35274	COUPLER ASSEMBLY	1,1,1		
--	25	37831	"O" RING COUPLER	1,1,1		
32	22	31164	BUSHING, REDUCER - COUPL	1,1,		
33	22	36171	TEE, LIFT HOSE TO REDUCER	1,1,		
34	22	35257	NIPPLE COUPLER TO CONNEC	1,1		
35	22	35269	CONNECTOR, LIFT HOSE TO C	1,1		