



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
		48170A 2	TRIM INDICATOR ASSTY, COMPL	1		
		48170A 3	TRIM INDICATOR ASS Y, COMPL	1		
-		48285A 2	TRIM INDICATOR ASSTY, COMPL	1		
-		48285A 3	TRIM INDICATOR ASSTY, COMPL	1		
1		48170A 1	SENDER ASSEMBLY, TRIM INC	1		
1		48170A 1	SENDER ASSEMBLY, TRIM INC	2		
1		48285A 1	SENDER ASSEMBLY, TRIM INC	1		
1		48285A 1	SENDER ASSEMBLY, TRIM INC	2		
2	10	45265	SCREW, BLEED - TRIM INDIC	2		
2	10	45265	SCREW, BLEED - TRIM INDIC	4		
3	25	45016	"O" RING, BLEED SCREW	2		
3	25	45016	"O" RING, BLEED SCREW	4		
4	10	20014	SCREW, SET - CABLE TO TRI	2		
4	10	20014	SCREW, SET - CABLE TO TRI	4		
5	11	37984	NUT, LOCK - GUIDE TUBE TO	1		
5	11	37984	NUT, LOCK - GUIDE TUBE TO	2		
6		48174	TUBE, GUIDE - TRIM INDICAT	1		
6		48174	TUBE, GUIDE - TRIM INDICAT	2		
7	22	48176	CONNECTOR, GUIDE TUBE	1		
7	22	48176	CONNECTOR, GUIDE TUBE	2		
8	22	48169	ELBOW, HYDRAULIC HOSE T	2		
8	22	48169	ELBOW, HYDRAULIC HOSE T	4		
9	10	25038	SCREW, TRIM INDICATOR SEN	2		
9	10	25038	SCREW, TRIM INDICATOR SEN	4		
9	10	48307	SCREW, TRIM INDICATOR SEN	1		
9	10	48307	SCREW, TRIM INDICATOR SEN	2		
9	10	48308	SCREW, TRIM INDICATOR SEN	1		
9	10	48308	SCREW, TRIM INDICATOR SEN	2		
10	13	21804	LOCKWASHER, TRIM INDICATI	2		
10	13	21804	LOCKWASHER, TRIM INDICATI	4		
10	12	38742	WASHER, TRIM INDICATOR SE	2		
10	12	38742	WASHER, TRIM INDICATOR SE	4		
11	11	23161	NUT, TRIM INDICATOR SENDE	2		
11	11	23161	NUT, TRIM INDICATOR SENDE	4		
12	23	38203	SLEEVE, HYDRAULIC TUBING	1		
12	23	38203	SLEEVE, HYDRAULIC TUBING	2		
13	32	52951A 1	TUBING, HYDRAULIC - SENDEF	1		
13	32	52951A 1	TUBING, HYDRAULIC - SENDEF	2		
13	32	52951A 1	TUBING, HYDRAULIC - SENDEF	1		
13	32	52951A 1	TUBING, HYDRAULIC - SENDEF	2		