



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	90983A 3	ELECTRIC START KIT	1		
1		816770	RECTIFIER ASSEMBLY	1		
2	10	48409	SCREW	2		
3	11	45076	NUT	3		
4	89	96054	STARTER SOLENOID	1		
5	10	40003 27	SCREW (14MM)	2		
6	11	26419	NUT (10-32)	2		
7	11	64015	NUT (1/4-20)	2		
8	84	88809A 5	WIRE ASSEMBLY (YELLOW)	1		
9	84	88439A 8	BATTERY WIRE ASSEMBLY (RI)	1		
9	84	88439A 6	BATTERY WIRE ASSEMBLY (BL)	1		
10		92439	BRACKET	1		
11	10	40003 27	SCREW	1		
12	11	40021 2	NUT	1		
13		86704A 2	STATOR ASSEMBLY	1		
14	10	40001 23	SCREW (30MM)	3		
15	50	90983A 1	STARTER MOTOR ASSEMBLY	1		
16		96561	DRIVE KIT	1		
17		96562	DRIVE	1		
18		96563	END CAP	1		
19		96565	ARMATURE	1		
20		96564	END CAP (W/SPRINGS AND E	1		
21	10	96566	THRU BOLT	1		
22	10	42125 1	SCREW	2		
23	43	99301	RING GEAR	1		
24	10	40039106	SCREW	4		
25	25	93770	GROMMET	1		