



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	87	95810A 6	ELECTRIC START KIT	-	QUANTITIES: (95810A6) - 1, (958	
-	87	95810A 8	ELECTRIC START KIT	-	QUANTITIES: (95810A6) - 0, (958	
-	87	95810A 9	ELECTRIC START KIT	-	QUANTITIES: (95810A6) - 0, (958	
-	87	95810A 2	ELECTRIC START KIT	-	QUANTITIES: (95810A6) - 0, (958	
1		95815	COVER (TOP)	-	QUANTITIES: (95810A6) - 1, (958	
2		95828	COVER (BOTTOM)	-	QUANTITIES: (95810A6) - 1, (958	
3	87	95810A 1	START SWITCH ASSEMBLY	-	QUANTITIES: (95810A6) - 1, (958	
3A		55741	BOOT	-	QUANTITIES: (95810A6) - 1, (958	
4	10	69570	SCREW (3/4")	-	QUANTITIES: (95810A6) - 1, (958	
5	84	95084A 2	WIRE ASSEMBLY	-	QUANTITIES: (95810A6) - 0, (958	
6	84	95084A 3	WIRE ASSEMBLY	-	QUANTITIES: (95810A6) - 0, (958	
7	88	79091	FUSE	-	QUANTITIES: (95810A6) - 0, (958	
8		95814	STRAP	-	QUANTITIES: (95810A6) - 1, (958	
9		95813	FASTENER	-	QUANTITIES: (95810A6) - 1, (958	
10	10	40019108	SCREW	-	QUANTITIES: (95810A6) - 1, (958	
11	10	90342	SCREW	-	QUANTITIES: (95810A6) - 1, (958	
11	10	40057 27	SCREW	-	QUANTITIES: (95810A6) - 2, (958	
12	87	93479A 4	NEUTRAL SWITCH ASSEMBLY	-	QUANTITIES: (95810A6) - 0, (958	
13		11036 1	BRACKET	-	QUANTITIES: (95810A6) - 0, (958	
14		12001	CAM	-	QUANTITIES: (95810A6) - 0, (958	
15	13	11052	LOCKWASHER	-	QUANTITIES: (95810A6) - 0, (958	
15	12	45771	WASHER	-	QUANTITIES: (95810A6) - 2, (958	
16	11	63683	NUT	-	QUANTITIES: (95810A6) - 0, (958	
17	84	79139A20	CABLE ASSEMBLY (RED)	-	QUANTITIES: (95810A6) - 1, (958	
18	10	11859 1	IDLE STOP SCREW	-	QUANTITIES: (95810A6) - 0, (958	
19	87	88890A 2	SWITCH	-	QUANTITIES: (95810A6) - 1, (958	
20		12153 2	GROMMET	-	QUANTITIES: (95810A6) - 1, (958	
21		42184	LINK	-	QUANTITIES: (95810A6) - 1, (958	
22	23	42182	BUSHING	-	QUANTITIES: (95810A6) - 1, (958	
23		42183	ACTUATOR	-	QUANTITIES: (95810A6) - 1, (958	
24	12	40023 16	WASHER	-	QUANTITIES: (95810A6) - 1, (958	
25	10	40011128	SCREW	-	QUANTITIES: (95810A6) - 1, (958	
26	10	62568	SCREW	-	QUANTITIES: (95810A6) - 1, (958	