

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	44369A 2	ELECTRIC START KIT	1		
1	50	44369A 1	STARTER MOTOR	1		
2		68575	DRIVE ASSEMBLY	1		
3		75660	DRIVE END PLATE	1		
4	10	95686	THRU BOLT	2		
5		75383	END CAP	1		
6		11957	ARMATURE	1		
7		75384	BRUSH SET	1		
8	23	57387	BUSHING	1		
9		N. S. S.	WASHER (AMER. BOSCH #w	1		2
10	13	26992	LOCKWASHER	1		
11	11	20890	NUT	1		
12		61787	BRUSH HOLDER	2		
13		N. S. S.	SCREW (AMER. BOSCH #024	2		2
14		90643	DRIVE KIT	1		
15	84	88807A31	WIRE	2		
16	10	69035	SCREW	1		
17	13	26992	LOCKWASHER	2		
18	11	64015	NUT (1/4-20)	1		
19		56703	COLLAR	2		
20		68042	STOP	2		
21	398	9710A25	STATOR	1		
22	84	12649A 4	HARNESS ASSEMBLY	1		
23	87	88107	KEY SWITCH	1	SEE (KEY CHOKE AND HORN KI	
24	11	93543	NUT	1		
25	87	813960A 3	SWITCH ASSEMBLY	1		
26	10	12110	SCREW	2		
27	89	96054	SOLENOID	1		
28	12	40023 14	WASHER	2		
29	84	88807A 6	CABLE (3-1/2")	1		
30	11	45076	NUT	3		
31		816770	RECTIFIER	1		
32	84	19061A 2	HARNESS	1		
33	11	26419	NUT (#8-32)	2		
34	13	26992	WASHER	2		
35	11	64015	NUT (1/4-20)	2		
36	84	79139A24	CABLE (9-1/4")	1		
37	84	88439A 9	CABLE (96")	1		
38	88	19637A 2	FUSE SOCKET	1		
39	88	812619	FUSE	1		

