



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		37135	FUEL PUMP ASSEMBLY	1	
2		37136	DIAPHRAGM, FUEL PUMP	1	
3	10	37144	SCREW, FUEL PUMP CLAMPIN	6	
4	12	37145	WASHER, FUEL PUMP CLAMP	6	
5	25	37143	"O" RING, FUEL PUMP FILTER	1	
6		37142	FILTER, FUEL PUMP	1	
7	23	37150	SLEEVE, FUEL PUMP FILTER	1	
8		37149	CAP, FUEL PUMP FILTER SLEE	1	
9		37146	BALE, FUEL PUMP	1	
10	10	37147	SCREW, FUEL PUMP BALE	1	
11	11	37148	NUT, FUEL PUMP BALE SCREW	1	
12	27	37137	GASKET, FUEL PUMP	2	(Part of 27-37073A1)
13		37138	PLATE, FUEL PUMP MOUNTING	1	
14	16	37112	STUD, FUEL PUMP TO CYLINDER	1	
15	10	37139	SCREW, FUEL PUMP TO CYLIND	1	
16	13	37141	LOCKWASHER, FUEL PUMP SCR	2	
17	11	37140	NUT, FUEL PUMP STUD	1	
18	32	38523	FUEL LINE, INLET-FUEL TANK TO	1	
19	32	38529	FUEL LINE, FUEL PUMP TO REAR	1	
20	22	28624	TEE, FUEL LINES TO REAR CARB	1	
21	1342	2564	CARBURETOR ASSEMBLY, REAR	1	
22	27	38531	GASKET, CARBURETOR MOUNT	2	(Part of 27-37097A1)
23	10	21339	SCREW, REAR CARBURETOR TO	1	
24	10	20639	SCREW, CARBURETOR INTAKE	3	
25	11	20102	NUT, CARBURETOR SCREW	4	
26		38508A	ADAPTOR ASSEMBLY, FLAME AR	1	
27		38509	ADAPTOR, FLAME ARRESTOR-FI	1	
28	27	38564	GASKET, FLAME ARRESTOR AD	2	(Part of 27-37097A1)
29	10	20646	SCREW, FLAME ARRESTOR ADA	4	
30	13	26996	LOCKWASHER, FLAME ARREST	4	
31		38567	ELEMENT, FLAME ARRESTOR	2	
32		38568	PLATE, FLAME ARRESTOR ELEM	2	
33	10	29794	SCREW, FLAME ARRESTOR PLA	4	
34	13	26996	LOCKWASHER, FLAME ARREST	4	
35	1342	2565	CARBURETOR ASSEMBLY, FRO	1	
36	32	38527	FUEL LINE, REAR CARBURETOR	1	
37		38672	HOOD, FLAME ARRESTOR	1	
38	10	29794	SCREW, FLAME ARRESTOR HO	4	
39	13	26996	LOCKWASHER, FLAME ARREST	4	
40	12	26013	WASHER, FLAME ARRESTOR HC	4	
41	19	22862	BUTTON PLUG, FLAME ARREST	2	