



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1336	2076	CARBURETOR ASSEMBLY, COM	1		
1	1397	2069	AIR HORN	1		
2			GASKET, AIR HORN	1		3,4,0
3	10	33048	SCREW, AIR HORN TO FLOAT	1		
4	10	33043	SCREW, AIR HORN TO FLOAT	7		
5	13	26996	LOCKWASHER, AIR HORN TO	8		
6			STRAINER, INLET NEEDLE AND	1		4,0
7			GASKET, INLET NEEDLE AND	1		3,4,0
8			INLET NEEDLE AND SEAT ASS	1		4,0
10	1397	2060	FLOAT ASSEMBLY	1		
11	17	33037	PIN, HINGE - FLOAT TO AIR HO	1		
12	1397	2075	FLOAT BOWL ASSEMBLY	1		
13	1397	2448	JET, FLOAT BOWL (STANDARC	2		
14			BALL, PUMP DISCHARGE - FLO	1		0
15			SPRING, PUMP DISCHARGE - F	1		0
16			GUIDE, PUMP DISCHARGE - FL	1		0
17	1397	2058	VENTURI CLUSTER ASSEMBLY	1		
18			GASKET, VENTURI CLUSTER	1		3,4,0
19	10	33034	SCREW, VENTURI CLUSTER T	1		
20			GASKET, VENTURI CLUSTER T	1		3,4,0
21	10	33033	SCREW, VENTURI CLUSTER T	2		
22	13	33029	LOCKWASHER, VENTURI CLUE	2		
23	1397	2048	LEVER, PUMP - AIR HORN	1		
24	10	33047	SCREW, AIR HORN PUMP LEVI	1		
25	1397	2054	PUMP SHAFT AND LEVER ASS	1		
26	1397	2051	ROD, PUMP	1		
27			CLIP, RETAINER - PUMP ROD	1		4,0
28			SPRING, FLOAT BOWL PUMP F	1		0
29			PUMP ASSEMBLY, FLOAT BOW	1		4,0
30			CLIP, RETAINER - FLOAT BOW	1		4,0
31	1397	2064	CHOKE HOUSING ASSEMBLY	1		
32			GASKET, CHOKE HOUSING	1		3,4,0
33	10	33053	SCREW, CHOKE HOUSING TO .	2		
34	1397	2050	PLUG, BALL - CHOKE HOUSIN	1		
35	19	33041	WELCH PLUG, CHOKE HOUSIN	1		
36	1397	2066	LEVER ASSEMBLY, CHOKE PIS	1		
37	1397	2059	CHOKE PISTON, CHOKE HOUS	1		
38	17	33049	PIN, CHOKE PISTON TO CHOKE	1		
39	10	33056	SCREW, CHOKE PISTON LEVE	1		
40	1397	2057	PALTE, BAFFLE-CHOKE HOUSI	1		
41			GASKET, STAT COVER AND CC	1		3,4,0