



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		32683	COVER, INTAKE MANIFOLD	1		
2	27	34047	GASKET, INTAKE MANIFOLD COV	1		
3	22	36382	PLUG, PIPE - INTAKE MANIFOLD	1		
4	10	34633	SCREW, INTAKE MANIFOLD COV	4		
5	10	34634	SCREW, INTAKE COVER TO EXH	8		
6	13	26992	LOCKWASHER, INTAKE MANIFOI	12		
7		32679	BODY, EXHAUST MANIFOLD	1	(NO LONGER AVAILABLE - ORD)	
8	16	34612	STUD, EXHAUST MANIFOLD BOU	4		
-	16	32908	STUD, EXHAUST MANIFOLD BOU	2	SERIAL 00000000-01564843	
9	10	21077	SCREW, EXHAUST MANIFOLD BI	2	SERIAL 01537451-01604624	
10	12	20553	WASHER, EXHAUST MANIFOLD	6		
11	13	37459	LOCKWASHER, EXHAUST MANIF	6		
12	11	24883	NUT, EXHAUST MANIFOLD BOD	4		
13	27	32816	GASKET, EXHAUST MANIFOLD B	1		
14		32797	COVER, CHOKE OVEN - EXHAUS	1		
15	27	32815	GASKET, CHOKE OVEN COVER	1		
16	10	28192	SCREW, CHOKE OVEN COVER T	2		
17	22	21373	CONNECTOR, CHOKE OVEN COV	1		
18		32684	ELBOW, WATER OUTLET - EXHA	1	SERIAL 00000000-01564843	
18		33481	ELBOW, WATER OUTLET - EXHA	1	SERIAL 01564844-01604624	
19	10	34634	SCREW, WATER OUTLET ELBO	5		
20	13	26992	LOCKWASHER, WATER OUTLET	5		
21	27	32814	GASKET, EXHAUST MANIFOLD E	1		
22	32	32751	HOSE, WATER OUTLET ELBOW	1	SERIAL 00000000-01537450	
22	32	33484	HOSE, WATER OUTLET ELBOW	1	SERIAL 01564844-01604624	
23	54	32781	CLAMP, HOSE TO WATER OUTL	2		
24		32877	COVER, WATER PUMP	1		
25	54	38426	CLAMP, WATER PUMP COVER T	1		
26	10	25299	SCREW, WATER PUMP FLANG (1		
27	22	32715	ELBOW, WATER INLET HOSE - E	1		
28	32	32844	HOSE, WATER INLET - EXHAUS	1		
29	54	32779	CLAMP, HOSE TO EXHAUST MA	2		
30	27	32809	GASKET, INNER WATER JACKET	1		
31		32680	COVER, WATER JACKET - INNE	1		
32	27	32810	GASKET, OUTER COVER TO INN	1		
33		32681	COVER, WATER JACKET - OUTE	1		
34	10	34633	SCREW, OUTER AND INNER COV	20		
35	13	26992	LOCKWASHER, OUTER AND INN	20		
36	22	32802	PLUG, PIPE - OUTER WATER JAC	1		
37	54	26550	CLIP, WIRING HARNESS TO OUT	1	SERIAL 00000000-01537450	
37	54	22740	CLIP, WIRING HARNESS TO OUT	1	SERIAL 01564844-01604624	