



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		33919	HOUSING, WATER OUTLET	1	SERIAL 00000000-01564843	
2	22	32804	PLUG, WATER OUTLET HOUSIN	1	SERIAL 00000000-01564843	
3	10	35169	SCREW, WATER OUTLET HOUS	2	SERIAL 00000000-01564843	
4	27	33918	GASKET, WATER OUTLET HOUS	1	SERIAL 00000000-01564843	
5		32718	BLOCK, DISTRIBUTION - WATER	1	SERIAL 00000000-01564843	
6	10	20359	SCREW, DISTRIBUTION BLOCK	1	SERIAL 00000000-01564843	
7	10	32774	SCREW, DISTRIBUTION BLOCK	2	SERIAL 00000000-01564843	
8	32	32752	HOSE, DISTRIBUTION BLOCK TC	1	SERIAL 00000000-01564843	
9	54	32780	CLAMP, HOSE TO DISTRIBUTION	2	SERIAL 00000000-01564843	
10	32	32749	HOSE, DISTRIBUTION BLOCK TC	1	SERIAL 00000000-01564843	
11	54	32781	CLAMP, HOSE TO DISTRIBUTION	2	SERIAL 00000000-01564843	
12		33483	ELBOW, WATER OUTLET - CYLIN	1	SERIAL 01564844-01604624	
13	10	21077	SCREW, WATER OUTLET ELBO	2	SERIAL 01564844-01604624	
14	22	32804	PLUG, PIPE - WATER OUTLET EL	1	SERIAL 01564844-01604624	
15	32	33485	HOSE, WATER OUTLET ELBOW	1	SERIAL 01564844-01604624	
16	54	32780	CLAMP, HOSE TO WATER OUTLI	2	SERIAL 01564844-01604624	
17	27	33680	GASKET, WATER OUTLET ELBO	1		
18		32682A	2 BODY ASSEMBLY, RELIEF VALVE	1		
19	24	35087A	1 SPRING ASSEMBLY, RELIEF VA	1		
20		35086	BUTTON, CHECK VALVE - RE	1		
21	27	32019	GASKET, RELIEF VALVE BODY	1		
22		32729A	1 CAP ASSEMBLY, RELIEF VALVE	1		
--	22	32802	PLUG, RELIEF VALVE BODY	1		
23	27	32811	GASKET, RELIEF VALVE BODY	1		
24	10	34634	SCREW, RELIEF VALVE BODY TC	7		
25	13	26992	LOCKWASHER, RELIEF VALVE B	7		
26		27711	RETAINER, RELIEF VALVE BODY	1		
27		32679	BODY, EXHAUST MANIFOLD	1	NO LONGER AVAILABLE - ORDE	
28	32	32843	HOSE, DRAIN - RELIEF BODY TO	1		
29	54	32779	CLAMP, DRAIN HOSE TO RELIEF	2		
30	22	32715	ELBOW, DRAIN HOSE - EXHAUS	1		
31		32723	CONTAINER, THERMOSTAT - EX	1		
32	27	32812	GASKET, THERMOSTAT CONTAI	1		
33	10	34634	SCREW, THERMOSTAT CONTAIN	5		
34		35884	THERMOSTAT	1		
35	27	32813	GASKET, EXHAUST ELBOW	1		
36		32724	ELBOW, EXHAUST - THERMOST.	1		
37	10	22421	SCREW, EXHAUST ELBOW TO T	4		
38	11	24652	NUT, EXHAUST ELBOW SCREW	4		
39	22	32803	PLUG, PIPE - EXHAUST ELBOW	1		
40	10	28667	SCREW, EXHAUST ELBOW TO T	1		