



| Parts List |       |          |                              |     |                          |          |
|------------|-------|----------|------------------------------|-----|--------------------------|----------|
| Ref        | Class | Part     | Description                  | Qty | Comment                  | Footnote |
| 1          | 50    | 32703    | STARTER MOTOR ASSEMBLY A10 F | 1   |                          |          |
| 2          | 23    | 34547    | SPACER, STARTER MOTOR        | 1   | SERIAL 00000000-01565234 |          |
| 3          | 10    | 34545    | BOLT, STARTER MOTOR MOUN     | 1   |                          |          |
| 4          | 10    | 34544    | BOLT, STARTER MOTOR MOUN     | 1   |                          |          |
| 5          | 12    | 32648    | WASHER, STARTER MOTOR BO     | 1   |                          |          |
| 6          |       | 32786    | TAB, STARTER MOTOR SOLENO    | 1   |                          |          |
| 7          | 10    | 20191    | SCREW, WIRING HARNESS LEA    | 1   | SEE NOTE                 |          |
| 8          | 13    | 26995    | LOCKWASHER, WIRING HARNE     | 1   |                          |          |
| 9          | 11    | 26419    | NUT, WIRING HARNESS LEAD S   | 1   |                          |          |
| 10         |       | 34546    | BRACE, STARTER MOTOR         | 1   |                          |          |
| 11         | 10    | 35765    | SCREW, BRACE TO STARTER M    | 2   |                          |          |
| 12         |       | 32786    | TAB, WIRING HARNESS LEAD T   | 1   |                          |          |
| 13         | 10    | 20191    | SCREW, WIRING HARNESS LEA    | 1   | SEE NOTE                 |          |
| 14         | 13    | 26995    | LOCKWASHER, WIRING HARNE     | 1   |                          |          |
| 15         | 11    | 26419    | NUT, WIRING HARNESS LEAD S   | 1   |                          |          |
| 16         | 11    | 28517    | NUT, SOLENOID SWITCH TERMI   | 1   |                          |          |
| 17         | 11    | 26419    | NUT, SOLENOID SWITCH TERMI   | 1   |                          |          |
| 18         |       | 32786    | TAB, STARTER MOTOR TO CYLII  | 1   |                          |          |
| 19         | 54    | 24871    | CLAMP, WIRING HARNESS TO S   | 1   | SERIAL 00000000-01565340 |          |
| 19         | 54    | 22627    | CLAMP, WIRING HARNESS TO S   | 1   | SERIAL 01564341-09999999 |          |
| 20         | 10    | 20191    | SCREW, WIRING HARNESS CLIF   | 1   |                          |          |
| 21         | 13    | 26995    | LOCKWASHER, WIRING HARNE     | 1   |                          |          |
| 22         |       | 22789    | "D" WASHER, WIRING HARNE     | 1   |                          |          |
| 23         | 11    | 26419    | NUT, WIRING HARNESS CLIP SC  | 1   |                          |          |
| 24         |       | 32701    | ALTERNATOR ASSEMBLY A10 F    | 1   | SERIAL 00000000-01729300 |          |
| 24         |       | 376151A1 | ALTERNATOR ASSEMBLY A10 F    | 1   | SERIAL 01564341-09999999 |          |
| 25         |       | 32754    | BRACE, ALTERNATOR TO CYLIN   | 1   |                          |          |
| 26         | 10    | 27165    | SCREW, ALTERNATOR BRACE T    | 1   |                          |          |
| 27         | 13    | 37459    | LOCKWASHER, ALTERNATOR BI    | 1   |                          |          |
| 28         | 12    | 20553    | WASHER, ALTERNATOR BRACE     | 1   |                          |          |
| 29         | 10    | 29198    | SCREW, ALTERNATOR BRACE T    | 1   |                          |          |
| 30         | 12    | 26168    | WASHER, ALTERNATOR BRACE     | 1   |                          |          |
| 31         | 10    | 32775    | SCREW, ALTERNATOR TO BRAC    | 1   |                          |          |
| 32         | 23    | 32727    | SPACER, ALTERNATOR SCREW     | 1   |                          |          |
| 33         | 11    | 25269    | NUT, ALTERNATOR SCREW        | 1   |                          |          |
| 34         |       | 32753    | BRACKET, ALTERNATOR MOUN     | 1   |                          |          |
| 35         | 10    | 27165    | SCREW, ALTERNATOR MOUNTII    | 1   |                          |          |
| 36         | 13    | 37459    | LOCKWASHER, ALTERNATOR M     | 1   |                          |          |
| 37         | 12    | 20553    | WASHER, ALTERNATOR MOUN      | 1   |                          |          |
| 38         |       | 32835    | BRACKET, ALTERNATOR MOUN     | 1   |                          |          |
| 39         | 10    | 22624    | SCREW, ALTERNATOR MOUNTII    | 1   |                          |          |