



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1336	2076	CARBURETOR ASSEMBLY, COM	1	SERIAL 00000000-02520424	
-	1336	3594A 1	CARBURETOR ASSEMBLY, COM	1	SERIAL 02520425-09999999	
1	1397	2069	AIR HORN	1	SERIAL 00000000-02520425	
1	1397	3823	AIR HORN	1	SERIAL 02520425-09999999	
2			GASKET AIR HORN	1		3,4
3	10	33048	SCREW, AIR HORN TO FLOAT	1		
4	10	33043	SCREW, AIR HOR TO FLOAT BI	7		
5	13	26996	LOCKWASHER, AIR HORN TO	8		
6			STRAINER, INLET NEEDLE ANI	1		4
7			GASKET, INLET NEEDLE AND	1		3,4
8			INLET NEEDLE AND SEAT ASS	1		4
10	1397	2060	FLOAT ASSEMBLY	1		
11	17	33037	PIN, HINGE - FLOAT TO AIR HO	1		
12	1397	2075	FLOAT BOWL ASSEMBLY	1		
13	1397	2448	JET, FLOAT BOWL(STANDARD)	2	SERIAL 00000000-02520424	
13	1397	3827	JET, FLOAT BOWL(STANARD)	2	SERIAL 02520425-09999999	
14			BALL, PUMP DISCHARGE - FLO	1		
15			SPRING, PUMP DISCHARGE - F	1		
16			GUIDE, PUMP DISCHARGE - FL	1		
17	1397	2058	VENTURI CLUSTER ASSEMBLY	1	SERIAL 00000000-02520424	
17	1397	3826	VENTURI CLUSTER ASSEMBLY	1	SERIAL 02510425-09999999	
18			GASKET, VENTURI CLUSTER	1		3,4
19	10	33034	SCREW, VENTURI CLUSTER T	1		
20			GASKET, VENTURI CLUSTER T	1		3,4
21	10	33033	SCREW, VENTURI CLUSTER T	2		
22	13	26995	LOCKWASHER, VENTURI CLUS	2		
23	1397	2048	LEVER, PUMP - AIR HORN	1		
24	10	33047	SCREW, AIR HORN PUMP LEVI	1		
25	1397	2054	PUMP SHAFT AND LEVER ASS	1		
26	1397	2051	ROD, PUMP	1		
27			CLIP, RETAINER - PUMP ROD	1		4
28			SPRING, FLOAT BOWL PUMP F	1		
29			PUMP ASSEMBLY, FLOAT BOW	1		4
30			CLIP, RETAINER - FLOAT BOW	1		4
31	1397	2064	CHOKEHOUSING ASSEMBLY	1		
32			GASKET, CHOKE HOUSING	1		3,4
33	10	33053	SCREW, CHOKE HOUSING TO.	2		
34	1397	2050	PLUG, BALL - CHOKE HOUSIN	1		
35	19	33041	WELCH PLUG, CHOKE HOUSIN	1		
36	1397	2066	LEVER ASSEMBLY, CHOKE PIS	1		
37	1397	2059	CHOKE PISTON, CHOKE HOUS	1		