



| | | | | Parts List | | |
|-----|-------|----------|----------------------------|------------|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 50 | 59799 | STARTER MOTOR ASSEMBLT (D | 1 | | |
| 1 | 50 | 69863A 1 | STARTER MOTOR ASSEMBLT (D | 1 | | |
| 2 | 10 | 34545 | BOLT, STARTER MOTOR MOUN | 1 | | |
| 3 | 10 | 34544 | BOLT, STARTER MOTOR MOUN | 1 | | |
| 4 | | 54671 | BRACE, STARTER MOTOR | 1 | | |
| 5 | 16 | 52387 | STUD, BRACE TO MOTOR AND C | 2 | | |
| 6 | 12 | 20103 | WASHER, BRACE STUD | 2 | | |
| 7 | 11 | 35814 | NUT, BRACE STUD | 2 | | |
| 8 | 11 | 32219 | NUT, SOLENOID SWITCH TERMI | 1 | | |
| 9 | 11 | 26419 | NUT, SOLENOID SWITCH TERMI | 1 | | |
| 10 | 13 | 26996 | LOCKWASHER, STARTER MOTO | 1 | | |
| 11 | 11 | 20645 | NUT, STARTER MOTOR TERMI | 1 | | |
| 12 | | 59755 | ALTERNATOR ASSEMBLY (DELC | 1 | | |
| 12 | | 69729 | ALTERNATOR ASSEMBLY (DELC | 1 | | |
| 12 | | 78403A 1 | ALTERNATOR ASSEMBLY (MOTC | 1 | | |
| 13 | | 32754 | BRACE, ALTERNATOR TO CYLIN | 1 | | |
| 14 | 10 | 27165 | SCREWM ALTERNATOR BRACE | 1 | | |
| 15 | 54 | 54178 | "J" CLIP, WATER TEMPERATUR | 1 | SERIAL 03377341-03461707 | |
| 16 | 13 | 37459 | LOCKWASHER, ALTERNATOR BI | 1 | | |
| 17 | 12 | 20553 | WASHER, ALTERNATOR BRACE | 1 | | |
| 18 | 10 | 29198 | SCREW, ALTERNATOR BRACE | 1 | | |
| 19 | 12 | 26168 | WASHER, ALTERNATOR BRACE | 1 | | |
| 20 | 10 | 56057 | SCREW, ALTERNATOR TO BRAC | 1 | | |
| 21 | 23 | 32727 | SPACER, ALTERNATOR SCREW | 1 | SERIAL 03377341-03461707 | |
| 21 | 23 | 45353 | SPACER, ALTERNATOR SCREW | 1 | SERIAL 03461708-09999999 | |
| 22 | 11 | 23161 | NUT, ALTERNATOR SCREW | 1 | | |
| 23 | 10 | 20055 | SCREW, LEAD TO ALTERNATOR | 1 | | |
| 24 | 13 | 26996 | LOCKWASHER, ALTERNATOR TI | 1 | | |
| 25 | 12 | 30164 | WASHER, ALTERNATOR TERMI | 1 | | |
| 26 | 12 | 20553 | WASHER, ALTERNATOR GROUN | 1 | | |
| 27 | 11 | 32219 | NUT, ALTERNATOR GROUND TE | 1 | | |
| 28 | 13 | 26991 | LOCKWASHER, ALTERNATOR S | 1 | | |
| 29 | 11 | 68531 | NUT, HARNESS TO ALTERNATO | 1 | | |
| 30 | | 52817 | BRACKET, ALTERNATOR MOUN | 1 | | |
| 31 | 10 | 33524 | SCREW, ALTERNATOR MOUNTII | 1 | | |
| 32 | 13 | 26993 | LOCKWASHER, ALTERNATOR M | 1 | | |
| 33 | 12 | 26825 | WASHER, ALTERNATOR MOUN | 1 | | |
| 34 | | 52818 | BRACKET, ALTERNATOR MOUN | 1 | | |
| 35 | 16 | 54177 | STUD, MOUNTING BRACKET TO | 1 | | |
| 36 | 16 | 54176 | STUD, MOUNTING BRACKET TO | 1 | | |
| 37 | 27 | 52502 | GASKET, ALTERNATOR MOUNTI | 1 | | |