



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	61975	WIRING HARNESS, EXTERNAL	1	SERIAL 03377341-03461707	
1	84	63715	WIRING HARNESS, EXTERNAL	1	SERIAL 03461708-03770649	
1	84	66962A	WIRING HARNESS, EXTERNAL	1	SERIAL 03370650-09999999	
2	10	29240	SCREW, WIRING HARNESS ATA	2	SERIAL 03461708-09999999	
3	12	24676	WASHER, WIRING HARNESS AT	2	SERIAL 03461708-09999999	
4		26079	PLATE, WIRING HARNESS TO FL	1		
5	54	53883	CLAMP, WIRING HARNESS PLAT	1	SERIAL 03377341-03461707	
6	10	46718	SCREW, WIRING HARNESS PLA	4		
7		47764	STRAP, NYLON - STARTER SOLE	1	SERIAL 03377341-03461707	
8		39593	BATTERY CABLE, POSITIVE	1	SERIAL 03377341-03461707	
8		39594	BATTERY CABLE, NEGATIVE	1	SERIAL 03377341-03461707	
9		63770	TAB HARNESS ATTACHING	2	SERIAL 03461708-09999999	
10		59816	CIRCUIT BREAKER	1	SERIAL 03377341-03770649	
11	10	36046	SREW, LEAD TO CIRCUIT BRE	2	SERIAL 03377341-03770649	
10	88	65093	CIRCUIT BREAKER	1	SERIAL 03770650-04952700	
--	11	20645	NUT, NUT HARNESS TO CIRCUI	2	SERIAL 03770650-09999999	
--	13	26996	LOCKWASHER, HARNESS TO CII	2	SERIAL 03770650-09999999	
10	88	78813	CIRCUIT BREAKER	1	SERIAL 04952701-09999999	
12		61800	BRACKET, CIRCUIT BREAKER	1	SERIAL 03377341-03461707	
12		62566	BRACKET, CIRCUIT BREAKER	1	SERIAL 03461708-09999999	
13	10	47618	SCREW, CIRCUIT BREAKER TO I	2		
14	12	47960	WASHER, CIRCUIT BREAKER AT	4		
15	25	61999	GROMMET, CIRCUIT BREAKER A	4		
16	23	61998	SPACER, CIRCUIT BREAKER BR	2	SERIAL 03377341-03461707	
16	23	63431	SPACER, CIRCUIT BREAKER BR	2	SERIAL 03461708-09999999	
17	11	46438	NUT, CIRCUIT BREAKER BRACK	2		
18	10	21077	SCREW, CIRCUIT BRAKER BRAC	2		
19	13	37459	LOCKWASHER, CIRCUIT BREAKI	2		
20	54	60517	CLAMP, HARNESS TO CIRCUIT B	1	SERIAL 03377341-03770649	
21	10	47194	SCREW, CLAMP TO BRACKET (S	1	SERIAL 03377341-03770649	
22	11	46438	NUT, CLAMP ATTACHING SCREW	1	SERIAL 03377341-03770649	
23		34623	OIL PRESSURE SENDER ASSEI	1		
24	13	26996	WASHER, WATER SENDER AND	2		
25	11	20645	NUT, WATER SENDER AND OIL	2		
26	22	32974	ADAPTOR, OIL PRESSURE SENC	1	SERIAL 03377341-03770649	
27	22	52930	FITTING, TEE - OIL PRESSURE S	1	SERIAL 03461708-04509241	
28	22	64698	FITTING, NIPPLE - OIL PRESSUR	1	SERIAL 03461708-04509241	
29		38559	SWITCH, OIL PRESSURE	1	SERIAL 03461708-04509241	
30		36525	WATER TEMPERATURE SENDEI	1		
31		25661	START SOLENOID	1	SERIAL 00000000-04469865	
31	88	68358	STARTER SOLENOID	1	SERIAL 04469865-09999999	