



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1351	7354A 1	CARBURETOR ASSEMBLY, COM	1	
1		N.S.S.	AIR HORN (ROCHESTER #7041)	1	
2			GASKET, AIR HORN	1	3,0
3	10	33043	SCREW, AIR HORN TO FLOAT	7	
4	10	33048	SCREW, AIR HORN TO FLOAT	1	
5	13	26996	LOCKWASHER, AIR HORN SCF	8	
6	1397	3330	NUT, FUEL INLET - AIR HORN	1	
7	35	53336	FILTER, FUEL INLET	1	
8	24	48143	SPRING, FUEL FILTER	1	
9			GASKET, FUEL INLET NUT	1	3,0
10	1397	2060	FLOAT ASSEMBLY	1	
11		N.S.S.	PIN, HINGE - FLOAT TO AIR HO	1	
12			INLET NEEDLE AND SEAT ASS	1	0
13			GASKET, INLET NEEDLE AND S	1	3,0
14	1397	2636	FLAT BOWL ASSEMBLY	1	
15		N.S.S.	VENTURI CLUSTER ASSEMBLY,	1	
16			GASKET, VENTURI CLUSTER	1	3,0
17		N.S.S.	SCREW, VENTURI CLUSTER T	1	
18			GASKET, VENTURI CLUSTER E	1	
19		N.S.S.	SCREW, VENTURI CLUSTER T	2	
20	13	26995	LOCKWASHER, VENTURI CLU	2	
21			GUIDE, PUMP DISCHARGE - FL	1	0
22			SPRING, PUMP DISCHARGE - F	1	0
23			BALL, PUMP DISCHARGE - FLO	1	0
24			POWER VALVE ASSEMBLY, FLI	1	0
25			GASKET, POWER VALVE	1	3,0
26	1397	2193	JET, FLOAT BOWL (STANDARC	2	
27			STRAINER, PUMP INLET	1	0
28	10	33047	SCREW, AIR HORN PUMP LEVI	1	
29		N.S.S.	PUMP SHAFT AND LEVER ASS	1	
30		N.S.S.	ROD, PUMP (ROCHESTER #70	1	
31			CLIP, RETAINER - PUMP ROD	1	0
32			PUMP ASSEMBLY, FLOAT BOW	1	0
33			CLIP, RETAINER - FLOAT BOW	1	0
34			SPRING, PUMP RETURN - FLO	1	0
35			BALL, CHECK - PUMP INLET - F	1	0
36			GASKET, THROTTLE BODY	1	3,0
37	1397	2639	THROTTLE BODY ASSEMBLY	1	
38			IDLE ADJUSTING NEEDLE, TH	2	0
39	24	33050	SPRING, IDLE ADJUSTING NEE	2	
40	1397	2639	IDLE STOP SCREW, THROTTLE	1	