



| Parts List | | | | | | |
|------------|-------|--------|-------------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 65897A | POWER STEERING MOUNTING KIT | 1 | | |
| - | | 65897A | POWER STEERING MOUNTING KIT | 1 | | |
| 1 | 57 | 68038 | "V" BELT, HYDRAULIC PUMP C | 1 | | |
| 1 | 57 | 69143 | "V" BELT, ALTERNATOR DRIVE | 1 | | |
| 2 | | 65608 | PULLEY, WATER CIRCULATING | 1 | | |
| 2 | | 73483 | PULLEY, WATER CIRCULATING | 1 | | |
| 3 | | 62253 | BRACKET, OIL COOLER | 1 | | |
| 4 | 54 | 37631 | CLAMP, OIL COOLER TO ENGINE | 2 | | |
| 5 | 10 | 27165 | SCREW, CLAMP FASTENING (3) | 2 | | |
| 6 | 13 | 35048 | LOCKWASHER, OIL COOLER CLAMP | 2 | | |
| 7 | 11 | 32219 | NUT, OIL COOLER CLAMP SCREW | 2 | | |
| 8 | | 49535 | OIL COOLER | 1 | | |
| 9 | 22 | 37760 | ELBOW, RETURN HOSE TO OIL COOLER | 2 | | |
| 10 | 32 | 66348 | HOSE, OUTLET - OIL COOLER | 1 | | |
| 11 | 54 | 32780 | CLAMP, INTAKE AND OUTLET HOSE | 2 | | |
| 12 | 32 | 64909 | HOSE, INTAKE - OIL COOLER TO ENGINE | 1 | | |
| 13 | 32 | 49533 | HOSE, RETURN - OIL COOLER TO ENGINE | 1 | | |
| 14 | 54 | 37295 | CLAMP, RETURN HOSE TO OIL COOLER | 2 | | |
| 15 | | 68040 | BRACKET, MOUNTING - HYDRAULIC PUMP | 1 | | |
| 16 | 10 | 34354 | SCREW, MOUNTING BRACKET | 2 | | |
| 17 | 13 | 35048 | WASHER, MOUNTING BRACKET | 2 | | |
| 18 | 10 | 34353 | SCREW, BRACKET TO HYDRAULIC PUMP | 1 | | |
| 19 | 10 | 34354 | SCREW, BRACKET TO HYDRAULIC PUMP | 1 | | |
| 20 | 13 | 35048 | LOCKWASHER, MOUNTING BRACKET | 1 | | |
| 21 | 12 | 25970 | WASHER, MOUNTING BRACKET | 1 | | |
| 22 | 23 | 56777 | SPACER, MOUNTING BRACKET | 1 | | |
| 23 | | 68039 | BRACKET, CIRCUIT BREAKER | 1 | | |
| 24 | 10 | 20776 | SCREW, BREAKER TO PUMP MOUNTING | 2 | | |
| 25 | 13 | 26992 | LOCKWASHER, CIRCUIT BREAKER | 2 | | |
| 26 | | 49181 | PULLEY, HYDRAULIC PUMP | 1 | | |
| 27 | 12 | 21901 | WASHER, HYDRAULIC PUMP | 1 | | |
| 28 | 11 | 25899 | NUT, PULLEY TO HYDRAULIC PUMP | 1 | | |
| 29 | | 68041 | BRACE, TENSION - HYDRAULIC PUMP | 1 | | |
| 30 | 10 | 37612 | SCREW, BRACE TO HYDRAULIC PUMP | 1 | | |
| 31 | 13 | 35048 | LOCKWASHER, TENSION BRACE | 1 | | |
| 32 | 12 | 25970 | WASHER, MOUNTING BRACKET | 1 | | |
| 33 | 23 | 36534 | SPACER, TENSION BRACE SCREW | 1 | | |
| 34 | 10 | 63826 | SCREW, BRACE TO ENGINE MOUNTING | 1 | | |