



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	424	2422	CAMSHAFT	1		
2	28	34466	KEY, CAMSHAFT GEAR	1		
3	23	34469	BEARING, CAMSHAFT THRUST	1		
4	43	58283	GEAR, TIMING	1		
5	10	34277	SCREW, TIMING GEAR TO CAMS	2		
6		46744	LIFTER, HYDRAULIC - TAPPET	8		
7		65142A 1	WATER PUMP ASSEMBLY (SPEC	1		
8	27	33956	GASKET, WATER PUMP	1		1
9	10	34471	SCREW, WATER PUMP TO CYLIND	2		
10	10	34505	SCREW, WATER PUMP TO CYLIND	2		
11		52349	PULLEY, WATER PUMP	1		
12	10	47277	SCREW, PULLEY AND HUB TO WA	4		
13	13	39107	LOCKWASHER, PULLEY AND HU	4		
14	32	46471	NOZZLE, OIL - TIMING GEAR	1		
15	57	64032	BELT, ALTERNATOR	1		
16	613	2277	CONNECTING ROD ASSEMBLY	4		
17	10	75539	BOLT, CONNECTING ROD BEAR	8		
18	11	58099	NUT, CONNECTING ROD CAP EN	8		
19	23	85677	BEARING (PAIR), CONNECTING F	4		
19	23	85678	BEARING (PAIR), CONNECTING F	AR		
19	23	85678	BEARING (PAIR), CONNECTING F	AR		
19	23	85679	BEARING (PAIR), CONNECTING F	AR		
19	23	85680	BEARING (PAIR), CONNECTING F	AR		
19	23	85681	BEARING (PAIR), CONNECTING F	AR		
20	423	2275	CRANKSHAFT	1		
21	28	34466	KEY, PULLEY AND GEAR LOCATI	2		
22	43	46743	GEAR, CRANKSHAFT	1		
23		34220	HUB, PULLEY - CRANKSHAFT	1		
24		35602	PULLEY, CRANKSHAFT	1		
25	10	35340	SCREW, PULLEY TO CRANKCAS	1		
25	10	34276	SCREW, PULLEY TO CRANKCAS	2		
26	220	8775	FLYWHEEL, CRANKSHAFT	1		
27	16	32808	STUD, FLYWHEEL TO ENGINE C	6		
28		38965A 2	ENGINE COUPLING ASSEMBLY	1	SERIAL 00000000-06018203	
28		32492A 5	ENGINE COUPLING ASSEMBLY	1	SERIAL 06018204-09999999	
29	12	35935	WASHER, FLYWHEEL STUD	6		
30	11	34933	NUT, FLYWHEEL STUD	6		