



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	76965A 3	STARTER MOTOR ASSEMBLY, C	1,...		
-	50	79604A 3	STARTER MOTOR ASSEMBLY, C	1,...		
-	50	79822A 2	STARTER MOTOR ASSEMBLY, C	1,...		
-	50	79821A 2	STARTER MOTOR ASSEMBLY, C	1,...		
38		71698	LEVER, SHIFT	1,...		
39		33310	SHAFT, SHIFT LEVER TO DRIV	1,...		
40	53	33354	RING, RETAINING - SHIFT LEV	1,1,1		
38		33297	LEVER, SHIFT	1,1,1,1		
41		N.S.S.	STUD, SHIFT LEVER TO DRIVE	1,1,1,1		
42	12	68615	WASHER, SHIFT LEVER STUD	1,1,1,1		
43	11	26484	NUT, SHIFT LEVER STUD	1,1,1,1		
44		33317	PLUNGER, SHIFT LEVER - SOL	1,1,1,1		
45	17	79207	PIN, PLUNGER TO SHIFT LEVE	1,1,1,1		
46	24	46889	SPRING, PLUNGER RETURN -	1,1,1,1		
47	10	28713	SCREW, SOLENOID SWITCH T	2,2,...		
47	10	24963	SCREW, SOLENOID SWITCH T	2,2,...		
48		33261	SOLENOID SWITCH ASSEMBLY	1,1,1,...		
48		89902	SOLENOID SWITCH ASSEMBLY	1,...		
49		33316	CONTRACT AND PUSH ROD.	1,1,1,...		
50	24	33265	SPRING, CONTRACT AND PU	1,1,1,...		
51		45537	COVER, SOLENOID SWITCH	1,1,1,...		
52	16	33304	STUD, RESISTOR TERMINAL	1,1,1,...		
53		33305	CONTRACT, RESISTOR TEF	1,1,1,...		
54	13	26996	LOCKWASHER, RESISTOR TI	1,1,1,...		
55	11	68219	NUT, RESISTOR TERMINAL	1,1,1,...		
56	16	33299	STUD, MOTOR TERMINAL (3	1,1,1,...		
57	16	45536	STUD, BATTERY TERMINAL	1,1,1,...		
58	12	33289	WASHER, BATTERY AND MO	2,2,2,...		
59	11	32219	NUT, BATTERY AND MOTOR	2,2,2,...		
60	13	37459	LOCKWASHER, BATTERY TE	1,1,1,...		
61	11	32219	NUT, BATTERY TERMINAL S	1,1,1,...		
62	16	32262	STUD, SWITCH TERMINAL (8	1,1,1,...		
63	54	33307	CLIP, SWITCH TERMINAL STI	1,1,1,...		
64	12	33279	WASHER, PLASTIC - SWITCH	2,2,2,...		
65	11	21923	NUT, SWITCH TERMINAL STI	2,2,2,...		
66	13	26995	LOCKWASHER, SWITCH TER	1,1,1,...		
67	10	33248	SCREW, COVER TO SOLEND	2,2,2,...		
68	12	33279	WASHER, PLASTIC - COVER	2,2,2,...		
69	10	48266	SCREW, FIELD COIL LEAD TC	1,1,1,...		
69	10	45546	SCREW, FIELD COIL LEAD TC	1,1,1,...		
70	12	26995	LOCKWASHER, FIELD COIL	1,1,1,...		