



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87581	DISTRIBUTOR ASSEMBLY, COM	1		
2		62426	SCREEN, VENT - DISTRIBUTOR	2		
3	43	33664	GEAR, DRIVE - MAIN SHAFT	1		
4		87597	MAIN SHAFT AND WEIGHT PL	1		
5	17	33649	PIN, DRIVE GEAR TO MAIN SH	1		
6		N.S.S.	WASHER, CAM AND SHAFT (DE	1		1
7	26	58219	SEAL, HOUSING	1		
8		33653	FELT, BREAKER CAM LUBRICA	1		
9		72654	RETAINER, BREAKER CAM LUB	1		
10		N.S.S.	PLATE, MOUNTING (DELCO-RE	1		1
11		N.S.S.	SCREW, MOUNTING PLATE (DI	2		1
12	12	62425	WASHER, BREAKER PLATE SL	2		
13		33662	CONDENSER	1		
14		48024	BRACKET, CONDENSER MOUN	1		
15	10	48021	SCREW, CONDENSER BRACKE	1		
16		34235	BREAKER ASSEMBLY, DISTRIB	1		
17	10	33650	SCREW, BREAKER ASSEMBLY	1		
18	25	33666	GROMMET, MOUNTING PLATE	1		
19		33658	LEAD, PRIMARY	1		
20		58217	ROTOR, DISTRIBUTOR	1		
21	12	36275	WASHER, ROTOR	1		
22	393	9459	CAP, DISTRIBUTOR	1		
23		N.S.S.	SCREW, DISTRIBUTOR CAP (8-	1		1
23		N.S.S.	SCREW, DISTRIBUTOR CAP (11	1		1
24	27	87707	GASKET, DISTRIBUTOR	1		3,4
25	84	813720A	5 SPARK PLUG WIRE KIT	1		
26	85	63709A	1 PROTECTOR, HIGH TENSION L	4		
27	33	59571	SPARK PLUG	4		
28		32782	RETAINER, HIGH TENSION LEA	1		
30		32193A	2 COIL, IGNITION	1		
31		65970	BRACKET, IGNITION COIL MOUN	1		
32	10	41408	SCREW, MOUNTING BRACKET T	1		
33	12	30164	WASHER, IGNITION COIL TERMI	2		
34	13	26996	LOCKWASHER, IGNITION COIL T	2		
35	11	68219	NUT, IGNITION COIL TERMINAL	2		
36	10	27165	SCREW, IGNITION COIL TO CYLI	1		
37	12	20553	WASHER, IGNITION COIL SCREW	1		
38	10	21077	SCREW, DISTRIBUTOR TO CYLI	1		
39		72624	CLAMP UNIT, DISTRIBUTOR	1		