



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	84	98422A 4	WIRING HARNESS (SHIFT COMP	1		2	
1	84	98422A10	WIRING HARNESS (SHIFT COMP	1		2	
1	84	98422A11	WIRING HARNESS (DIGITAL IGN	1			
2		26079	PLATE, WIRING HARNESS - MET	1			
3	10	34696	SCREW, PLATE - METAL	4			
2		26079A 2	PLATE ASSEMBLY, WIRING HAR	1			
3	10	15001	SCREW, PLATE - PLASTIC	4			
4		98428A 2	BRACKET, MOUNTING (CONVEN	1			
4A		19427T	BRACKET, MOUNTING (DIGITAL	1			
5		97257A 1	WATER TEMPERATURE SENDEI	1			
5		49734A 1	WATER TEMPERATURE SENDEI	OPT			
6	13	26996	LOCKWASHER, WATER TEMPE	1			
7	11	68219	NUT, WATER TEMPERATURE	1			
8		90806	OIL PRESSURE SENDER ASSEM	1			
8		37293	OIL PRESSURE SENDER ASSEM	OPT			
9	13	26996	LOCKWASHER, OIL PRESSURE	1			
10	11	68219	NUT, OIL PRESSURE SENDER	1			
11	22	32974	ADAPTOR, OIL PRESSURE SENC	1			
12	88	11178	CIRCUIT BREAKER (50 AMP)	AR			
12	88	93582	CIRCUIT BREAKER (60 AMP)	AR			
13	13	26996	LOCKWASHER, CIRCUIT BREAKI	2			
14	11	68219	NUT, CIRCUIT BREAKER TERMIN	2			
15	10	45862	SCREW, CIRCUIT BREAKER (7/8	2			
16	11	46438	NUT, INSULATOR SCREW	2			
17	89	96158	STARTER SOLENOID	1			
18	10	98256	SCREW, STARTER SOLENOID	2			
19	11	20586	NUT, STARTER COLENOID SCRE	2			
20	13	26992	LOCKWASHER, STARTER SOLEI	2			
21	11	26419	NUT, STARTER SOLENOID TERM	2			
22	11	94330	NUT, STARTER SOLENOID TERM	2			
23		45315	TERMINAL BLOCK	1	- USE WITH RING TERMINALS		
24	10	62568	SCREW, TERMINAL BLOCK (3/8"	1	- USE WITH RING TERMINALS		
24	10	35519	SCREW, TERMINAL BLOCK (1/2"	1	- USE WITH RING TERMINALS		
25	84	94227A 2	RESISTANCE CABLE KIT (TO REF	1			
-	84	11149A 5	ADAPTOR KIT	1	THIS KIT IS USED TO ADAPT "F		