



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		45514A 1	GIMBAL HOUSING ASSEMBLY (S)	1	
1		45637A 1	GIMBAL HOUSING ASSEMBLY (P)	1	
1		45702A 1	GIMBAL HOUSING ASSEMBLY (P)	1	
2	16	37270	STUD, GIMBAL HOUSING TO T	2	
3	31	32536	BEARING, ROLLER - GIMBAL H	1	
4	26	32911	OIL SEAL, LOWER GIMBAL HO	2	
5	23	38634	BUSHING, SYNTHANE - GIMBA	1	
6	26	32540	OIL SEAL, UPPER GIMBAL HO	1	
7	22	21290	PLUG, PIPE - GIMBAL HOUSIN	1	
8	22	31345	FITTING, GREASE - GIMBAL HC	1	
9		29359	LUBRICAP, GIMBAL HOUSING	1	
10	26	36143	SEAL, GREASE - GIMBAL HOUS	1	
11	23	35130	ADAPTOR, BEARING CARRIER	1	
12	30	36418	BEARING, BALL - GIMBAL HOUS	1	
13	53	35128	RING, RETAINING - BEARING C	1	
14	15	35244A 1	SHIM, GIMBAL HOUSING BEAR	AR	
15	10	25612	SCREW, DRIVE-GIMBAL HOUSI	13	
16	25	20863	"O" RING, GIMBAL HOUSING	1	
--		46443	EMBLEM, GIMBAL HOUSING	1	
17		34762A 1	PLATE ASSEMBLY, INHIBITOR -	1	
18	10	34763	SCREW, INHIBITOR PLATE TO	2	
19	17	45212	PIN, SWIVEL - GIMBAL HOUSING	1	
20	18	34159	COTTER PIN, RETAINING - LOWE	1	
21	12	32518	WASHER, GIMBAL HOUSING TO	1	
22	10	35624	BOLT, GIMBAL HOUSING TO TR	2	
23	12	32620	WASHER, GIMBAL HOUSING BOI	2	
24		31659	BELLOWS, SHIFT ACTUATING CA	1	
25	54	38863	CLAMP,ACTUATING CABLE BELL	1	
26	54	31766	CLAMP, SHIFT ACTUATING CABL	1	
27	12	22248	WASHER, GIMBAL HOUSING STI	2	
28	11	34933	NUT, GIMBAL HOUSING STUD	2	
29	32	32631	TUBE, WATER - GIMBAL HOUSIN	1	
30	23	28055	BUSHING, RUBBER - WATER TU	1	
31		32517	COVER, WATER TUBE SEALING	1	
32	10	28635	SCREW, WATER TUBE SEALING	2	
33		45530A 2	ELBOW ASSEMBLY, EXHAUST (A	1	
33		53272A 1	ELBOW ASSEMBLY, EXHAUST (A	1	
33		53113A 2	ELBOW ASSEMBLY, EXHAUST (A	1	
34		45798	BRACKET,SUPPORT - WATER	(1) 2	
35	10	45813	SCREW, SUPPORT BRACKET	(2) 4	
36	11	45912	NUT, SUPPORT BRACKET SCR	(2) 4	