



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1547	5523A18	DRIVE SHAFT HOUSING ASSEM	1		
2	16	56295	STUD,DRIVE SHAFT HOUSING	2		
3	22	31704	PLUG,PIPE-DRIVE SHAFT HOU	1		
4	19	32652	WELCH PLUG,DRIVE SHAFT HI	1		
5	23	32632	BUSHING,DRIVE SHAFT HOUS	1		
6	11	34933	NUT,GEAR HOUSING TO DRIVE	3		
7		54235A 2	COVER ASSEMBLY,WATER POCI	1		
8	26	36557	SEAL,RUBBER-WATER POCKE	1		
9	27	55810	GASKET,WATER POCKET COV	1		
10	10	28668	SCREW,WATER POCKET COVE	4		
11	32	54236	TUBE,WATER-WATER POCKE	1		
12	19	32298	PLUG,TRIM TAB HOLE-DRIVE SF	1		
13	37	56480A 1	DECAL SET,DRIVE SHAFT HOU	1	SERIAL 00000000-04530701	
14	37	76731A 1	DECAL SET,DRIVE SHAFT HOU	1	SERIAL 04530702-09999999	
15	37	76749	DECAL,DRIVE SHAFT HOUSING	1	SERIAL 04530702-09999999	
16	37	76750	DECAL,DRIVE SHAFT HOUSING	1	SERIAL 04530702-09999999	
17	37	76751	DECAL,DRIVE SHAFT HOUSING	2	SERIAL 04530702-09999999	
18	10	28634	SCREW,DRIVE SHAFT HOUSING	2		
19	12	20260	WASHER,DRIVE SHAFT HOUSIN	2		
20	26	37259	OIL SEAL,DRIVE SHAFT HOUSIN	1		
21	26	32511	OIL SEAL,GEAR CHAMBER-DRIV	1		
22	15	36178A 1	SHIM,BEARING CUP TO DRIVE S	AR		
23	31	35990A 1	TAPERED ROLLER BEARING AS	1		
24	43	55766A 2	GEAR ASSEMBLY,COMPLETE-ME	1	(20-24 GEAR RATIO)-7.98 RATIO	
24	43	55765A 2	GEAR ASSEMBLY,COMPLETE-ME	1	(24-24 GEAR RATIO)-1.65 RATIO	
25	45	55796	DRIVE SHAFT,UPPER	1		
26	25	55801	"O" RING,UPPER DRIVE SHAFT	1		
27		55758	COVER, TOP-DRIVE SHAFT HOU	1	SERIAL 00000000-03134193	
28	31	32575A 1	BEARING ASSEMBLY,DRIVE SHA	1	SERIAL 00000000-03134193	
29	23	55798	SPACER,UPPER DRIVE SHAFT	1	SERIAL 00000000-03134193	
30	24	55797	SPRING,UPPER DRIVE SHAFT(TI	1	SERIAL 00000000-03134193	
27		61102A 1	COVER ASSEMBLY, TOP-DRIVE S	1	SERIAL 03213658-03443920	
28	31	61100A 1	BEARING ASSEMBLY,DRIVE SF	1	SERIAL 03213658-03443920	
30	24	55797	SPRING,UPPER DRIVE SHAFT	1	SERIAL 03213658-03443920	
27		62266A 1	COVER ASSEMBLY, TOP-DRIVE S	1	SERIAL 03469428-04530701	
28	31	61100A 1	BEARING ASSEMBLY,DRIVE SF	1	SERIAL 03469428-04530701	
30	15	45691A 1	SHIM,BEARING CUP TO COVER	AR	SERIAL 03469428-04530701	
27		76098A 1	COVER ASSEMBLY, TOP-DRIVE S	1	SERIAL 04530702-09999999	
28	31	61100A 1	BEARING ASSEMBLY,DRIVE SF	1	SERIAL 04530702-09999999	
30	15	45691A 1	SHIM,BEARING CUP TO TOP CI	AR	SERIAL 04530702-09999999	
27		22546	"O" RING, TOP COVER SEALING	1		