

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		48165A	5 REVERSE LOCK VALVE ASSEMB	1	USED WITH REVERSE INTER-L	
1		76812A	4 REVERSE LOCK VALVE ASSEMB	1	USED WITHOUT REVERSE INTI	
2		45709	FOLLOWER, ACM	1		
3	22	48166	ELBOW, HYDRAULIC TRIM HO:	1	SERIAL 00000000-03780849	
3	22	45794	ELBOW, HYDRAULIC TRIM HO:	1	SERIAL 03780850-09999999	
4	22	48167	CONNECTOR, ELBOW	1		
5	22	52644	PLUG, PIPE - REVERSE LOCK V	1		
6	13	25906	WASHER, WAVE - REVERSE LI	1		
7	25	45710	"O" RING, REVERSE LOCK VAL	1		
8		45526	CAM, REVERSE LOCK VALVE	1		
9	10	46736	SCREW, CAM TO CAM LEVER	1		
10	13	26996	LOCKWASHER, CAM SCREW	1		
11		45528A	2 COVER ASSEMBLY, REVERSE	1		
11A	12	59570	WASHER, REVERSE LOCK VA	1		
12	25	45711	"O" RING, VALVE COVER	1		
13	30	45712	BALL, VALVE COVER	30		
14	12	45713	WASHER, RETAINING - BALL T	1		
15	10	45716	SCREW, COVER TO REVERSE	4		
16	11	20110	NUT, COVER SCREW	4		
17		46732A	1 LEVER ASSEMBLY, CAM	1		
18	16	45715	STUD, SHIFT CONTROL LEVE	2		
19		46482A	1 SWITCH ASSEMBLY, REVERSE I	1	SERIAL 00000000-03780849	
19		46482A	2 SWITCH ASSEMBLY, REVERSE I	1	SERIAL 03780850-04530701	
20		45717	SHIELD, CUT-OUT SWITCH	1	USED WITH B-48165A5 REVER	
21	10	58332	SCREW, SHIELD AND SWITCH T	2	USED WITH B-48165A5 REVER	
22	54	22740	CLIP, CUT-OUT SWITCH LEAD	1	USED WITH B-48165A5 REVER	
23	10	35519	SCREW, CUT-OUT SWITCH LEAD	1	USED WITH B-48165A5 REVER	
22	54	64855	CLIP, CUT-OUT SWITCH LEAD	1	USED WITH B-48165A5 REVER	
23	10	21643	SCREW, CUT-OUT SWITCH LEAD	1	USED WITH B-48165A5 REVER	
24		22789	"D" WASHER, CLIP ATTACHING	2	USED WITH B-48165A5 REVER	
25	10	25299	SCREW, REVERSE LOCK VALVE	2		
26	13	21804	LOCKWASHER, REVERSE LOCK	2		
27		49702A	2 LEVER ASSEMBLY, SHIFT CONTI	1	SERIAL 00000000-03443920	
27		63333A	2 LEVER ASSEMBLY, SHIFT CONTI	1	SERIAL 03469428-03780849	
27		66397A	1 LEVER ASSEMBLY, SHIFT CONTI	1	SERIAL 03780850-09999999	
28	12	21273	WASHER, CAM LEVER STUD	2		
29	11	20110	NUT, SHIFT CONTROL LEVER TC	2		

